


UNDERSTANDING SOUND FROM EAR TO ENGINEER




Geoffrey Dunbar
Pasadena City College

Understanding Sound from Ear to Engineer

by Geoffrey Dunbar



an Open Educational Resource
published by
Pasadena City College
2026



This text is disseminated via the Open Education Resource (OER) LibreTexts Project (<https://LibreTexts.org>) and like the thousands of other texts available within this powerful platform, it is freely available for reading, printing, and "consuming."

The LibreTexts mission is to bring together students, faculty, and scholars in a collaborative effort to provide an accessible, and comprehensive platform that empowers our community to develop, curate, adapt, and adopt openly licensed resources and technologies; through these efforts we can reduce the financial burden born from traditional educational resource costs, ensuring education is more accessible for students and communities worldwide.

Most, but not all, pages in the library have licenses that may allow individuals to make changes, save, and print this book. Carefully consult the applicable license(s) before pursuing such effects. Instructors can adopt existing LibreTexts texts or Remix them to quickly build course-specific resources to meet the needs of their students. Unlike traditional textbooks, LibreTexts' web based origins allow powerful integration of advanced features and new technologies to support learning.



LibreTexts is the adaptable, user-friendly non-profit open education resource platform that educators trust for creating, customizing, and sharing accessible, interactive textbooks, adaptive homework, and ancillary materials. We collaborate with individuals and organizations to champion open education initiatives, support institutional publishing programs, drive curriculum development projects, and more.

The LibreTexts libraries are Powered by [NICE CXone Expert](#) and was supported by the Department of Education Open Textbook Pilot Project, the California Education Learning Lab, the UC Davis Office of the Provost, the UC Davis Library, the California State University Affordable Learning Solutions Program, and Merlot. This material is based upon work supported by the National Science Foundation under Grant No. 1246120, 1525057, and 1413739.

Any opinions, findings, and conclusions or recommendations expressed in this material are those of the author(s) and do not necessarily reflect the views of the National Science Foundation nor the US Department of Education.

Have questions or comments? For information about adoptions or adaptations contact info@LibreTexts.org or visit our main website at <https://LibreTexts.org>.

This text was compiled on 05/01/2026

TABLE OF CONTENTS

Licensing

1: The Characteristics of Sound

- 1.1: Introduction
- 1.2: The Sound Wave
- 1.3: Frequency
- 1.4: Amplitude
- 1.5: Velocity
- 1.6: Wavelength
- 1.7: Acoustical Phase
- 1.8: Sound Envelope
- 1.9: Direct, Early, and Reverberant Sound
- 1.10: Conclusion

2: The Auditory System

- 2.1: Introduction
- 2.2: The Ear
- 2.3: How Hearing Works
- 2.4: Hearing Loss
- 2.5: Symptoms of Hearing Loss
- 2.6: Hearing Protection
- 2.7: Hearing Aids and Cochlear Implants
- 2.8: Fun Fact. How Loud Is Too Loud?
- 2.9: Sound Pressure Level (SPL)
- 2.10: Tinnitus- The Ringing in the Ears
- 2.11: Conclusion

3: Psychoacoustics

- 3.1: Introduction
- 3.2: Properties of Sound
- 3.3: Frequency Spectrum
- 3.4: Octave Groupings
- 3.5: Instrument Ranges
- 3.6: Equal Loudness Principle
- 3.7: Quality of Sound (Timbre)
- 3.8: Binaural Hearing vs. Stereo Hearing
- 3.9: Conclusion

4: Audio Mixers, Consoles, and DAW Control Surfaces

- 4.1: Introduction
- 4.2: Faders vs. Knobs
- 4.3: Passive vs. Active
- 4.4: Function of a Mixer/Console
- 4.5: Balance and Combine Levels

- 4.6: Monitoring and Metering
- 4.7: The Mix Bus and Bussing
- 4.8: Routing and Signal Flow
- 4.9: Major Sections of a Mixer/Console
- 4.10: Broadcast vs. Production Consoles
- 4.11: Features of Most Consoles
- 4.12: The Audio Patchbay
- 4.13: Automation
- 4.14: DAW Control Surfaces
- 4.15: Conclusion

5: Audio Recording

- 5.1: Introduction
- 5.2: Digital vs. Analog
- 5.3: Sample Rate
- 5.4: Nyquist-Shannon Theory
- 5.5: Bit Depth (Resolution)
- 5.6: Quantization
- 5.7: Binary Code
- 5.8: Common Recording Systems
- 5.9: The Digital Audio Workstation
- 5.10: Audio Interface
- 5.11: Digital Audio Connections
- 5.12: Recording Media Types
- 5.13: MIDI and Its Use
- 5.14: Analog Audio Connectors
- 5.15: Digital Audio Networking
- 5.16: Conclusion

6: The Microphone

- 6.1: Introduction
- 6.2: Transducer
- 6.3: Impedance
- 6.4: Dynamic vs. Condenser vs. Ribbon
- 6.5: Moving Coil Principle
- 6.6: Ribbon Mic Principle
- 6.7: Condenser Mic Principle
- 6.8: Microphone Construction
- 6.9: Directional Response
- 6.10: Frequency Response
- 6.11: Mic Limitations
- 6.12: Proximity Effect
- 6.13: Humbucker Coils in Microphones
- 6.14: Lavalier Mic Properties and Uses
- 6.15: Other Varieties of Mics
- 6.16: Wireless Mics
- 6.17: Microphone Accessories
- 6.18: XLR Cables
- 6.19: Conclusion

7: Speakers and Headphones

- 7.1: Introduction
- 7.2: The Audio Signal Chain
- 7.3: Speaker Function
- 7.4: The Speaker as a Transducer
- 7.5: Types of Speakers
- 7.6: Drivers and Frequency Bands
- 7.7: Speaker Cabinet Design and Construction
- 7.8: Active vs. Passive Speakers
- 7.9: Polarity and Phase
- 7.10: Crossover Networks
- 7.11: Bi-Amplification
- 7.12: Power Amplifiers
- 7.13: Characteristics of Monitoring Systems
- 7.14: Monitoring Systems- Stereo and Mono
- 7.15: Headphones
- 7.16: Headphone Monitoring in Studios
- 7.17: Conclusion

8: Audio Signal Processing and Processors

- 8.1: Introduction
- 8.2: Function of a Signal Processor
- 8.3: Spectrum Processors
- 8.4: Time Domain Processors
- 8.5: Amplitude Processors
- 8.6: Noise Processors
- 8.7: External vs. Internal Signal Processors
- 8.8: Digital vs. Analog Signal Processing
- 8.9: Conclusion

9: The Mixing Process

- 9.1: Introduction
- 9.2: Purpose of Mixing
- 9.3: Layering vs. Balancing
- 9.4: Mixing Perspective and Panning (Music Focused)
- 9.5: Stages of the Mixing Process
- 9.6: The Mastering Process
- 9.7: Signal Processing in Mixing
- 9.8: Dynamic Range
- 9.9: Audio Imaging for TV and Film
- 9.10: Surround Sound Mixing
- 9.11: Conclusion

10: Audio Over the Internet

- 10.1: Introduction
- 10.2: Streaming Audio
- 10.3: Subscription-Based Listening
- 10.4: Audio File Formats

- [10.5: Audio File Size and Bitrate Considerations](#)
- [10.6: Audio Quality vs. File Size](#)
- [10.7: Podcasting](#)
- [10.8: What Happened to Terrestrial Radio?](#)
- [10.9: Alternatives to Streaming](#)
- [10.10: The Future of Audio](#)
- [10.11: Conclusion](#)

[Index](#)

[Glossary](#)

[Detailed Licensing](#)

[Video Tutorials](#)

[Detailed Licensing](#)

Licensing

If you find any mistakes, issues, or areas for improvement within this text, please fill out our Comments and Recommendations Form to let our team know so we can improve this book in the future, and thank you for reading our book!


This text has been peer reviewed, checked for accessibility, and Inclusion, Diversity, Equity, and Antiracism reviewed.

Cover image: Will Francis, My home studio podcasting setup - a Røde NT1A microphone, AKG K171 headphones, desk stand with pop shield and my iMac running Reaper, May 19, 2020, Free to use Unsplash license.

 Understanding Sound from Ear to Engineer © 2026 by Geoffrey Dunbar is licensed under a [Creative Commons Attribution-Share Alike 4.0 International License](https://creativecommons.org/licenses/by-sa/4.0/), except where otherwise noted.

CHAPTER OVERVIEW

1: The Characteristics of Sound



1.1: Introduction

1.2: The Sound Wave

1.3: Frequency

1.4: Amplitude

1.5: Velocity

1.6: Wavelength

1.7: Acoustical Phase

1.8: Sound Envelope

1.9: Direct, Early, and Reverberant Sound

1.10: Conclusion

This page titled [1: The Characteristics of Sound](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

1.1: Introduction

Introduction

Sound is a fascinating phenomenon that plays a crucial role in the way we perceive and interact with the world around us. Understanding how sound behaves can help us in various fields such as acoustics, music, post-production, broadcasting, engineering, and even psychology. This chapter delves into the fundamental aspects of sound, focusing on its key characteristics: the sound wave, frequency, amplitude, velocity, wavelength, acoustical phase, sound envelope, and the interaction between direct and reverberant sound.

This page titled [1.1: Introduction](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

1.2: The Sound Wave

The Sound Wave




Figure 1.2.1: Sound Wave, Badseed, (CC BY-SA 3.0 , via [Wikimedia Commons](#))

A sound wave is a mechanical wave that propagates through a medium such as air, water, or solids. It is produced when an object vibrates, creating moments of compression and rarefaction that travel through the medium. These waves transfer energy from one point to another without transporting matter. The two motions of a sound wave are Compression and Rarefaction (expansion).

Compression is defined as a region in a medium where particles are pushed closer together, resulting in higher density and pressure. An example is when a speaker cone moves forward, it compresses the air in front of it, squeezing the air particles together.

Rarefaction is defined as a region in a medium where particles are spaced farther apart, resulting in lower density and pressure. An example is when a speaker cone pulls backward, it creates a rarefaction as the air particles spread out to fill the larger space.

There are two primary types of sound waves:

1. **Longitudinal Waves (common):** The particles of the medium move parallel to the direction of wave propagation. This is the type of wave we typically encounter in sound.
2. **Transverse Waves:** The particles of the medium move perpendicular to the direction of wave propagation, although this is less common for sound in air.

Sound waves in air are usually described as longitudinal waves because the air particles vibrate back and forth along the same line the wave travels. The resulting pressure variations in the medium are what we perceive as sound.

This page titled [1.2: The Sound Wave](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

1.3: Frequency

Frequency

The frequency of a sound wave refers to the number of cycles (or oscillations) that occur per second, measured in Hertz (Hz). It determines the pitch of the sound; higher frequencies produce higher-pitched sounds, while lower frequencies result in lower-pitched sounds. Think of higher pitched sounds coming from the upper keys of a piano, while the lower pitched sounds would come from the lower keys.

Human Hearing Range

The typical human ear can hear sounds in the frequency range from about **20 Hz to 20,000 Hz** (20 kHz). Sounds below 20 Hz are considered **infrasound**, while those above 20 kHz are categorized as **ultrasound**. Many animals, such as dogs and bats, can hear frequencies outside the human range, which is why they may react to sounds we cannot hear.

This page titled [1.3: Frequency](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

1.4: Amplitude

Amplitude

Amplitude refers to the maximum displacement of the particles in the medium from their equilibrium position during a sound wave's propagation. It is related to the energy and intensity of the sound. Larger amplitudes correspond to louder sounds, while smaller amplitudes produce quieter sounds. We would normally equate the term amplitude with the volume of a sound.

In more technical terms, amplitude is often described as the **pressure variation** or **displacement** in the medium caused by the sound wave. The louder the sound, the greater the pressure variation and, hence, the larger the amplitude. Amplitude is usually measured in decibels (dB), a logarithmic unit that quantifies sound intensity.

The Decibel Scale

The decibel scale is a relative scale, meaning it compares the intensity of a sound to a reference intensity. A sound at 0 dB corresponds to the faintest sound the average human ear can detect. This is referred to as the **Threshold of Hearing**. However, sounds above 120 dB can potentially cause hearing damage with prolonged exposure, sometimes referred to as the **Threshold of Pain**.

The decibel is a unit of measurement to describe or compare the intensity of acoustic or electrical signal, named for American inventor Alexander Graham Bell (1847 to 1922). Measurements are typically given in tenths of a bel, or **decibels**. (tenths = deci, bel) The bel represents the common logarithm (base 10) of the ratio between two quantities. For example, a power ratio of 10 is equal to 1 bel.

This page titled [1.4: Amplitude](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

1.5: Velocity

Velocity

The velocity of sound refers to how fast the sound wave propagates through the medium. The speed at which sound travels depends on the properties of the medium, including temperature, pressure, and the medium's density.

In air at room temperature (70°F), the speed of sound is approximately **1,130 feet per second**. However, sound travels faster in denser media, such as water or steel, because particles are closer together and can transmit the wave's energy more quickly.

Factors Affecting Velocity

- **Temperature:** As temperature increases, the velocity of sound in air increases because the molecules move faster and collide more frequently, facilitating faster transmission of sound.
- **Medium:** The speed of sound is faster in solids than in liquids or gases due to the greater density and elasticity of solid materials.

This page titled [1.5: Velocity](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

1.6: Wavelength

Wavelength

Wavelength is the distance between two consecutive points in phase within a sound wave, such as from one compression to the next. It is inversely related to frequency: the higher the frequency of a sound, the shorter the wavelength. Conversely, low-frequency sounds have long wavelengths.

This page titled [1.6: Wavelength](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

1.7: Acoustical Phase

Acoustical Phase

The **acoustical phase** of a sound wave refers to the position of the wave relative to a reference point in time. Since sound waves are periodic, each cycle of the wave has a specific phase that determines where it begins in its oscillation pattern. Phase is important for understanding how different sound waves interact with each other.

Constructive and Destructive Interference

When two sound waves meet, they can interfere with each other. If the waves are in phase (i.e., their compressions and rarefactions align), they combine to create a sound of greater amplitude (constructive interference). If the waves are out of phase (i.e., the compression of one wave coincides with the rarefaction of another), they can cancel each other out (destructive interference).

Phase differences are crucial in areas such as **stereo sound systems**, where speakers are arranged to create different phase relationships, enhancing spatial perception of sound.

This page titled [1.7: Acoustical Phase](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

1.8: Sound Envelope

Sound Envelope




Figure 1.8.1: ADSR, Tobias R. – Metoc, (CC BY-SA 2.5; author via [Wikimedia Commons](#))

The **sound envelope** refers to the way a sound's amplitude changes over time, particularly how it evolves from the start of the sound to its eventual decay. The envelope is often broken down into four stages usually expressed as ADSR:

1. **Attack:** The initial onset of the sound, where its amplitude rises quickly.
2. **Decay:** After the attack, the amplitude begins to decrease.
3. **Sustain:** The sound maintains a relatively constant amplitude during this phase.
4. **Release:** Finally, the sound fades to silence.

These stages are critical in music and acoustics for describing the characteristic behavior of sounds, such as a piano note or a vocal sound. The shape of the envelope affects how we perceive the "liveness" or "sharpness" of a sound.

This page titled [1.8: Sound Envelope](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

1.9: Direct, Early, and Reverberant Sound

Direct, Early, and Reverberant Sound

In any enclosed space, sound behaves in multiple ways, depending on the surface characteristics and geometry of the room. The behavior of sound can be broken down into:

Direct Sound

Direct sound is the sound that travels directly from the source to the listener without reflecting off any surfaces. This is the sound we hear first, and it provides the clearest representation of the original signal.

Early Reflections

Before sound reaches the listener after multiple bounces off walls, floors, and ceilings, it may reflect off nearby surfaces. These **early reflections** arrive shortly after the direct sound and can affect the perception of the sound's location, size, and clarity. In music, early reflections contribute to the richness and spatial quality of the sound.

Reverberant Sound

Reverberation is the series of reflections that continue to bounce around a space after the original sound has stopped. This creates a sense of space and ambiance. In large concert halls or theaters, reverberation is carefully controlled to ensure clarity and fullness of sound. Reverberation time (RT60) is a key metric used to describe the amount of time it takes for sound to decay by 60 dB.

The Reverberation Effect

The interaction between direct sound, early reflections, and reverberant sound plays a crucial role in how we perceive the acoustic characteristics of a room. Too much reverberation can make sounds muddled, while too little can make a space feel dry or unnaturally sterile.

In architectural acoustics, designers strive to balance these elements to create spaces with optimal sound quality.

This page titled [1.9: Direct, Early, and Reverberant Sound](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

1.10: Conclusion

Conclusion

The behavior of sound encompasses a wide range of physical and perceptual phenomena. By understanding the intricacies of sound waves, frequency, amplitude, velocity, wavelength, phase, the sound envelope, and the interaction of direct and reverberant sound, we can better understand how sound affects our daily lives and environments. Whether designing a concert hall or fine-tuning a musical performance, these fundamental principles serve as the foundation for any acoustical analysis or application.

This page titled [1.10: Conclusion](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

CHAPTER OVERVIEW

2: The Auditory System

- [2.1: Introduction](#)
- [2.2: The Ear](#)
- [2.3: How Hearing Works](#)
- [2.4: Hearing Loss](#)
- [2.5: Symptoms of Hearing Loss](#)
- [2.6: Hearing Protection](#)
- [2.7: Hearing Aids and Cochlear Implants](#)
- [2.8: Fun Fact. How Loud Is Too Loud?](#)
- [2.9: Sound Pressure Level \(SPL\)](#)
- [2.10: Tinnitus- The Ringing in the Ears](#)
- [2.11: Conclusion](#)

This page titled [2: The Auditory System](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

2.1: Introduction

Introduction

Hearing is one of the most essential human senses, allowing us to communicate, be aware of our surroundings, appreciate music, and connect with the world. The ear is a remarkably intricate organ that transforms tiny vibrations in the air into electrical signals the brain can understand, combining delicate mechanical structures with complex neurological pathways. This chapter explores how the ear works, the different ways hearing can be damaged, and the steps we can take to protect it. By understanding both the anatomy of the ear and the science of sound, we gain insight into how easily hearing can be harmed—and how vital it is to preserve our ability to hear throughout our lives.

This page titled [2.1: Introduction](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).


2.2: The Ear

The Ear

The ear is a complex organ responsible for detecting sound and helping with balance. It converts sound waves into electrical signals the brain can interpret.

The Ear's Three Main Parts:

1. **Outer(External) Ear:** Gathers sound.
2. **Middle Ear:** Transmits sound.
3. **Inner Ear:** Converts sound to electrical signals.



“Structures of the Ear”, [Openstax](#), (CC BY 4.0)

This page titled [2.2: The Ear](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

2.3: How Hearing Works

How Hearing Works

Step-by-Step:

1. **Sound Collection:** The *pinna* (outer ear) collects sound waves and funnels them into the *ear canal*.
 2. **Vibration:** Sound waves strike the *eardrum*, causing it to vibrate.
 3. **Amplification:** Vibrations are passed to the ossicles (the three smallest bones in the body: *malleus*, *incus*, *stapes*) in the middle ear.
 4. **Conversion:** Vibrations enter the *cochlea* (inner ear), filled with fluid and tiny hair cells that detect different frequencies.
 5. **Signal Transmission:** Hair cells convert vibrations into electrical signals sent to the brain via the *auditory nerve*.
-

This page titled [2.3: How Hearing Works](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

2.4: Hearing Loss

Hearing Loss

Hearing loss can be sudden or gradual, and it affects millions of people worldwide. It is categorized into three types:

Types of Hearing Loss:

Table of hearing loss types, causes and area affected.

Type	Cause	Affected Area
Conductive	Blockage (wax, fluid, bone damage)	Outer/Middle ear
Sensorineural	Damage to cochlea or auditory nerve	Inner ear
Mixed	Mix of conductive and sensorineural	Both

Causes of Hearing Loss:

- Aging (Presbycusis): Most common cause of hearing decline over time.
- Noise Exposure: Prolonged loud sound damages the hair cells (stereocilia).
- Infections: Chronic ear infections can damage ear structures.
- Ototoxic Medications: Certain drugs harm the inner ear.
- Genetics: Inherited condition affecting ear development.
- Injury or Trauma: Head injuries can damage hearing pathways.

This page titled [2.4: Hearing Loss](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

2.5: Symptoms of Hearing Loss

Symptoms of Hearing Loss

- Muffled speech and sounds
- Frequently asking others to repeat
- Turning up the volume excessively
- Difficulty understanding conversations, especially in noise
- Ringing in the ears (tinnitus)

This page titled [2.5: Symptoms of Hearing Loss](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

2.6: Hearing Protection

Hearing Protection

Ways to Protect Hearing:

1. **Avoid Loud Noises:**

- Use the **60/60 Rule** for headphones (60% volume for max 60 minutes).
- Stay away from loud speakers at events or wear ear protection.

2. **Use Ear Protection:**

- **Earplugs** or **noise-canceling headphones** in noisy environments.
- Custom-molded earplugs for musicians or industrial workers.

3. **Monitor Volume Levels:**

- Install decibel meter apps on phones.
- Keep volume below 85 dB when listening to music.

4. **Get Regular Hearing Checks:**

- Especially important for people over 50 or in noisy workplaces.

5. **Avoid Inserting Objects Into Ears:**

- Cotton swabs and other objects can damage the ear canal and eardrum.

This page titled [2.6: Hearing Protection](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

2.7: Hearing Aids and Cochlear Implants


Hearing Aids and Cochlear Implants

Hearing Aids:

- Amplify sounds.
- Suitable for mild to moderate hearing loss.
- Worn behind or inside the ear.

Cochlear Implants:

- Surgically implanted.
- For severe sensorineural hearing loss.
- Bypass damaged inner ear and directly stimulate the auditory nerve.



“Blausen 0244 CochlearImpant1”, Bruce Blaus, (CC BY 3.0).

This page titled [2.7: Hearing Aids and Cochlear Implants](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

2.8: Fun Fact. How Loud Is Too Loud?

Fun Fact. How Loud Is Too Loud?

Decibel levels of normal sounds.

Sound Source	Approx. Decibel Level (dB)
Heavy traffic	85 dB
Normal conversation	60 dB
Rock concert	110 dB
Jet engine (close range)	140+ dB

Hearing damage risk begins at 85 dB with prolonged exposure!

This page titled [2.8: Fun Fact. How Loud Is Too Loud?](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

2.9: Sound Pressure Level (SPL)

Sound Pressure Level (SPL)

Sound Pressure Level (SPL) is a measure of the pressure variation in the air caused by a sound wave, compared to a reference level. It is measured in **decibels (dB)** and reflects how loud a sound is to the human ear. The scale is logarithmic—every 10 dB increase represents a tenfold increase in sound intensity. For example, a 100 dB sound is 10 times more intense than 90 dB and 100 times more intense than 80 dB.


High SPLs can damage the delicate structures in the inner ear, especially with prolonged or repeated exposure. That's why monitoring and managing sound levels is crucial for hearing health.

Sound Pressure Levels of Common Sources

Table showing various sound sources and their volume.

Sound Source	SPL (dB)	Risk of Hearing Damage
Rustling leaves	20 dB	None
Whisper	30 dB	None
Quiet room	40 dB	None
Normal conversation	60 dB	None
Busy street	70–75 dB	Low (if prolonged)
Alarm clock (1 m away)	80 dB	Possible risk (prolonged)
Heavy traffic	85–90 dB	Risk with long exposure
Power tools (e.g., drill, saw)	100 dB	Risk after 15+ minutes
Rock concert / Nightclub	110 dB	Risk after a few minutes
Siren (close proximity)	120 dB	Immediate danger
Firecracker/Gunshot (near ear)	140–160 dB	Instant damage possible

Note: OSHA recommends limiting exposure to 85dB for 8 hours. For every 3dB increase, exposure time should be cut in half.



"Sound Pressure Graph", GDunbar, (CC BY-SA 4.0).

- Green dashed line at 0dB: The threshold of hearing, the quietest sound a healthy person can detect.
- Red dashed line at 85dB: Risk of hearing damage with prolonged exposure.

- Orange dashed line at 130dB: Threshold of pain, where sound can cause immediate discomfort or damage.

This page titled [2.9: Sound Pressure Level \(SPL\)](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

2.10: Tinnitus- The Ringing in the Ears

Tinnitus: The Ringing in the Ears

Tinnitus is the perception of sound when no external sound is present. It is often described as a ringing, buzzing, hissing, or clicking noise in one or both ears. For some, it is a mild nuisance; for others, it can be severely disruptive to sleep, focus, and quality of life.

Causes of Tinnitus:

Tinnitus is not a disease itself but a **symptom of an underlying condition**. Common causes include:

- **Noise-induced hearing loss:** Damage from loud music, machinery, or explosions.
- **Age-related hearing loss (presbycusis):** Common in older adults.
- **Earwax blockage:** Can alter ear pressure and lead to temporary tinnitus.
- **Ear or sinus infections:** Causes congestion and pressure behind the ear drum.
- **Certain medications:** Especially high doses of aspirin, NSAIDs, antibiotics, or chemotherapy drugs.
- **Meniere's disease:** Inner ear disorder affecting balance and hearing.
- **Head or neck injuries:** Can affect blood flow and trigger nerve or muscle issues. (concussion)
- **Stress and anxiety:** Can amplify the perception of tinnitus.

Types of Tinnitus:

Table showing types of hearing loss.

Type	Description	Commonality
Subjective	Heard only by the person	Very common
Objective	Sometimes heard by a doctor	Very rare
Pulsatile	Matches the rhythm of your heartbeat	Often vascular-related

Treatment and Management:

There is no universal cure for tinnitus, but **various treatments** help manage it:

- **Hearing aids:** Improve hearing and reduce tinnitus perception.
- **Sound therapy:** White noise machines, nature sounds, or background music.
- **Cognitive Behavioral Therapy (CBT):** Reduces distress and anxiety related to tinnitus.
- **Tinnitus retraining therapy (TRT):** Combines sound therapy with counseling.
- **Stress management:** Relaxation techniques like yoga or meditation can help.
- **Avoid caffeine, alcohol, and smoking,** which can worsen symptoms in some people.

Important Note: If tinnitus is sudden, persistent, or occurs with hearing loss or dizziness, medical evaluation is necessary to rule out serious causes.

This page titled [2.10: Tinnitus- The Ringing in the Ears](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

2.11: Conclusion

Conclusion

The ear is a delicate yet powerful organ essential for communication and connection. Understanding how it works—and how to protect it—is key to lifelong hearing health. With growing exposure to noise in modern life, being mindful of sound environments and using protective strategies can help prevent hearing loss.

This page titled [2.11: Conclusion](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

CHAPTER OVERVIEW

3: Psychoacoustics

- [3.1: Introduction](#)
- [3.2: Properties of Sound](#)
- [3.3: Frequency Spectrum](#)
- [3.4: Octave Groupings](#)
- [3.5: Instrument Ranges](#)
- [3.6: Equal Loudness Principle](#)
- [3.7: Quality of Sound \(Timbre\)](#)
- [3.8: Binaural Hearing vs. Stereo Hearing](#)
- [3.9: Conclusion](#)

This page titled [3: Psychoacoustics](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

3.1: Introduction

Psychoacoustics is the study of how humans perceive and interpret sound—bridging the gap between physical acoustics and the psychological processes of hearing. It explores how the brain analyzes vibrations in the air and transforms them into sensations of pitch, loudness, timbre, spatial location, and tonal balance. By understanding the frequency spectrum, octave structures, instrument ranges, equal loudness principle, and the differences between binaural and stereo hearing, we gain insight into why sounds are experienced the way they are, and how this knowledge can be applied to audio engineering, music production, and acoustic design.

This page titled [3.1: Introduction](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

3.2: Properties of Sound

Properties of Sound

Sound can be described using four fundamental properties:

- **Pitch:** How high or low a sound is, determined by the frequency of the wave.
- **Amplitude:** The intensity or loudness of the sound, related to the size of the wave's vibration.
- **Timbre (pronounced Tamber):** The unique quality or color of a sound that distinguishes one source from another, even when pitch and loudness are the same.
- **Duration:** The length of time a sound persists.




Figure 3.2.1: "CH5-graphic2", [Lois Frankle](#), ([CC BY-NC-ND 4.0](#)).

This page titled [3.2: Properties of Sound](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

3.3: Frequency Spectrum

Frequency Spectrum

As mentioned in chapter 1, the human ear is sensitive to sound frequencies ranging from **20 Hz to 20,000 Hz (20 kHz)**. This spectrum can be divided into categories:

- **Infrasound:** Below 20 Hz (not perceivable by humans).
- **Audible Range:** 20 Hz – 20 kHz.
- **Ultrasound:** Above 20 kHz.

Different frequencies correspond to different perceptions of pitch. Low frequencies are heard as deep bass, while high frequencies are perceived as treble or high end.

The spectrum is divided into equal parts called **octaves**. Each octave is further subdivided into **12 pitches** (the chromatic scale). This system, rooted in the work of **Pythagoras**, reflects mathematical ratios in string lengths that correspond to harmonious intervals, laying the foundation for Western musical tuning.

For practical listening and mixing, octaves are grouped into general sections: **Bass, Midrange, and Treble**. More specifically, the frequency spectrum can be grouped as follows:

- **Low Bass:** 20 Hz – 80 Hz
- **Upper Bass / Lower Midrange:** 80 Hz – 320 Hz
- **Midrange:** 320 Hz – 2,560 Hz
- **Upper Midrange:** 2,560 Hz – 5,120 Hz

Treble: 5,120 Hz – 20,000 Hz

This page titled [3.3: Frequency Spectrum](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

3.4: Octave Groupings

Octave Groupings

In music and acoustics, an **octave** represents a doubling of frequency. For example:

- 100 Hz → one octave higher = 200 Hz.
- 200 Hz → one octave higher = 400 Hz.

The octave system allows classification of sound frequencies into manageable bands. Human perception of pitch is logarithmic, making octave divisions useful in both music and sound engineering.

This page titled [3.4: Octave Groupings](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

3.5: Instrument Ranges

Instrument Ranges

Different musical instruments occupy characteristic frequency ranges:

- **Piano:** 27 Hz – 4,186 Hz (A0 to C8).
- **Violin:** 196 Hz – 3,520 Hz.
- **Flute:** 262 Hz – 2,093 Hz.
- **Trumpet:** 165 Hz – 988 Hz.
- **Human Voice:**
 - Bass: ~82 Hz – 330 Hz
 - Soprano: ~250 Hz – 1,050 Hz




Figure 3.5.1: “Estensione Strumenti Musicale”, Alexyo.Netcom, (CC BY-SA 3.0).

This page titled [3.5: Instrument Ranges](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

3.6: Equal Loudness Principle

Equal Loudness Principle

The **Equal Loudness Contour** (Fletcher-Munson curves) shows that the human ear does not perceive all frequencies as equally loud, even when played at the same intensity. For example, a 40 Hz tone must be played louder than a 1,000 Hz tone to be perceived as equally loud.

This principle is crucial in audio engineering and sound design, as it influences mixing, mastering, and audio production.




Figure 3.6.1: "Equal loudness", Nick84 (talk)Lindos1.svg, (Public domain).

This page titled [3.6: Equal Loudness Principle](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

3.7: Quality of Sound (Timbre)

Quality of Sound (Timbre)

Timbre is the quality or color of a sound that makes one source distinct from another, even when pitch and loudness are the same. It arises from:

- The **harmonic content** of the sound.
- The **attack, sustain, and decay** characteristics.
- **Resonance** of the instrument or voice.

Overtones play a large part in the timbre of sounds, as they enrich the harmonic structure and create unique sonic identities for instruments and voices.

For example, a clarinet and a piano playing the same note at the same loudness will sound different due to their unique harmonic overtones.




Figure 3.7.1: "Timbre perception", Rburtonresearch, CC BY-SA 4.0.

This page titled [3.7: Quality of Sound \(Timbre\)](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

3.8: Binaural Hearing vs. Stereo Hearing

Binaural Hearing vs. Stereo Hearing

Binaural Hearing: Refers to natural human hearing with two ears. It allows for localization of sounds through:

- **Interaural Time Difference (ITD):** Small differences in arrival time of a sound at each ear.
- **Interaural Level Difference (ILD):** Differences in intensity between ears.
- **Spectral Cues:** Shaping of sound by the outer ear (pinna).

Sound is **omnidirectional**, meaning it radiates in all directions. Both ears must work in tandem to determine the location of a sound, relying on the brain's ability to process differences between the two auditory signals. Binaural hearing also allows us to perceive **depth, breadth, and height** in our sound environment, giving a three-dimensional sense of space.

- **Stereo Hearing:** Refers to artificially reproduced two-channel audio systems. Stereo creates a sense of spatial placement of sound sources but does not fully replicate natural 3D localization. It is essentially **two-dimensional**, relying on **two speakers** to replicate the stereo spectrum of sound.

This page titled [3.8: Binaural Hearing vs. Stereo Hearing](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

3.9: Conclusion

Conclusion

Psychoacoustics reveals how the human brain interprets the physical characteristics of sound and transforms them into meaningful auditory experiences. By understanding the principles behind pitch, loudness, timbre, frequency groupings, octave structures, instrument ranges, and spatial hearing, we gain insight into why sound is perceived the way it is and how these perceptions shape music, speech, and environmental awareness. Whether designing audio systems, producing music, or studying human hearing, psychoacoustics provides the essential foundation for connecting acoustical science with human experience.

This page titled [3.9: Conclusion](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

CHAPTER OVERVIEW

4: Audio Mixers, Consoles, and DAW Control Surfaces

- 4.1: Introduction
- 4.2: Faders vs. Knobs
- 4.3: Passive vs. Active
- 4.4: Function of a Mixer/Console
- 4.5: Balance and Combine Levels
- 4.6: Monitoring and Metering
- 4.7: The Mix Bus and Bussing
- 4.8: Routing and Signal Flow
- 4.9: Major Sections of a Mixer/Console
- 4.10: Broadcast vs. Production Consoles
- 4.11: Features of Most Consoles
- 4.12: The Audio Patchbay
- 4.13: Automation
- 4.14: DAW Control Surfaces
- 4.15: Conclusion

This page titled [4: Audio Mixers, Consoles, and DAW Control Surfaces](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.1: Introduction

Introduction

Audio mixers, consoles, and digital audio workstation (DAW) control surfaces are the central hubs of sound recording, reinforcement, and broadcast environments. They allow the operator to combine, shape, and route signals, making them indispensable tools in both professional and creative audio work. This chapter explores their core concepts, functions and the differences between analog and digital workflows.

This page titled [4.1: Introduction](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.2: Faders vs. Knobs

Faders vs. Knobs

Mixers and consoles use both faders and knobs to control audio levels, but each offers unique advantages.

- **Faders** are sliding controls, usually linear, that provide a visual and tactile reference for level adjustments. Their long throw makes it easier to make fine adjustments and see relative balances across channels at a glance.
- **Knobs** (or rotary potentiometers) are compact and versatile, often used for equalization (EQ), gain trim, or auxiliary sends. While they save space, they do not provide the same visual overview as faders.

Many consoles use a combination of both, reserving faders for volume control and knobs for tone and routing adjustments.

This page titled [4.2: Faders vs. Knobs](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.3: Passive vs. Active

Passive vs. Active

Mixers can be categorized as **passive** or **active**:

- **Passive mixers** use only resistors and lack built-in amplification. They simply combine signals but cannot increase gain, requiring an external preamp or amplifier.
- **Active mixers** incorporate powered circuits and amplifiers, offering gain control, EQ, and signal shaping. Virtually all professional consoles are active, as they provide greater flexibility and control.

This page titled [4.3: Passive vs. Active](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.4: Function of a Mixer/Console

Function of a Mixer/Console

The primary functions of a mixer or console include:

- **Amplification:** Boosting weak microphone or instrument signals to usable line levels through preamplifiers.
- **Balancing:** Adjusting levels so that no sound source dominates or disappears, ensuring a clear and coherent mix.
- **Signal Processing:** Applying EQ, dynamics, and filters to shape the tonal and dynamic characteristics of each source.
- **Combining:** Summing multiple inputs together into subgroups or the main mix bus.
- **Routing:** Directing signals to specific outputs, such as speakers, recorders, or broadcast feeds.

Essentially, the mixer acts as the command center for all audio signals in a given environment.

This page titled [4.4: Function of a Mixer/Console](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.5: Balance and Combine Levels

Balance and Combine Levels

Mixers allow engineers to combine multiple sound sources while controlling their relative levels. This balancing ensures that vocals, instruments, and effects occupy the right space in the mix. Proper level control prevents distortion, maintains clarity, and achieves the desired artistic or technical outcome.

This page titled [4.5: Balance and Combine Levels](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.6: Monitoring and Metering

Monitoring and Metering

Monitoring allows engineers to listen to and evaluate the mix through headphones or speakers. Metering provides visual feedback of levels, helping to avoid distortion and maintain consistent loudness. Both tools are critical for maintaining audio integrity and meeting technical standards.

It is important to remember that **the ear should be the ultimate judge of audio quality**. While meters are excellent tools, they should not be relied upon exclusively. The **visual meter** is a good starting point for inspecting audio levels, as it can alert the engineer to issues such as clipping or distortion. However, meters cannot fully represent tonal balance, dynamics, or the subjective perception of sound. Engineers must always trust their ears to evaluate clarity, warmth, balance, and artistic intent, using meters only as a supplementary guide.

Practical Tips for Monitoring and Metering

- **Use multiple listening environments:** Check mixes on studio monitors, headphones, and small speakers to ensure they translate well.
- **Balance sight with sound:** Use meters to catch clipping, distortion, or overly low signals, but always verify with listening.
- **Pay attention to fatigue:** Take breaks to avoid ear fatigue, which can distort perception of loudness and frequency balance.
- **Reference professional mixes:** Compare your mix against well-mastered tracks to calibrate your ears and maintain perspective.
- **Use meters for consistency, not creativity:** Let your ears guide artistic decisions such as EQ, dynamics, and panning; rely on meters for technical assurance.
- **Check in mono:** Periodically collapse the mix to mono to check for phase issues or imbalance that meters might not reveal.

Meter Types



Figure 4.6.1: “VU Meter”, by Iainf, (CC BY-SA 3.0).

Monitor meters measure **voltage**, which corresponds to signal strength. There are three primary types of meters used in audio engineering:

- **VU (Volume Unit) Meter:** Measures **average program energy** over time, giving a good indication of perceived loudness but responding too slowly to display short peaks. Example: Keeping vocal levels steady in a broadcast.
- **PPM (Peak Program Meter):** Measures the **peaks** of a signal, providing fast response to transient spikes that could cause distortion. Example: Watching for clipping on percussion hits.
- **Loudness Meter:** A modern standard that measures **both average energy and peaks**, designed to align more closely with human hearing perception. Example: Meeting loudness standards for television or streaming services.

By understanding and using all three types of meters appropriately, engineers can combine technical precision with critical listening to achieve accurate, musical, and compliant audio mixes.

The Monitoring Section of a Console

Every console includes a **monitoring section**, which manages how the engineer listens to the mix and other signals. This section routes audio to various monitor devices such as:

- **Headphones:** Provide isolated, detailed listening, often used during tracking sessions or for checking fine details in a mix.

- **Studio Monitors (speakers):** Offer a more natural listening environment to evaluate how a mix will sound in real-world playback systems.

The monitoring section typically allows the engineer to switch between multiple sets of speakers, control monitor levels, and route solo or cue mixes for critical listening.

Talkback System

Part of the monitoring section is the **Talkback system**, which provides communication from the control room to performers or talent in the studio. A small microphone built into the console (or attached externally) allows the engineer to speak directly into the headphone or monitor feeds of musicians. Talkback is essential for coordinating takes, giving instructions, and saving time during recording sessions.

Oscillator for Signal Calibration

Many consoles also include an **oscillator** in the monitoring section, which generates test tones (commonly 1 kHz sine wave). These tones are used to:

- Calibrate signal levels through the system.
- Test the routing of signals across patchbays and consoles.
- Align tape machines, outboard processors, or DAWs to consistent reference levels.

The monitoring section, therefore, is not just about listening—it is about communication, calibration, and ensuring that the engineer can evaluate audio accurately in any situation.

This page titled [4.6: Monitoring and Metering](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.7: The Mix Bus and Bussing

The Mix Bus and Bussing

The **mix bus** is the summing path where multiple channel signals are combined. Bussing refers to the act of routing (send or return) signals to a common destination.

Examples include:

- **Stereo mix bus:** The main left/right output of the console.
- **Subgroup buses:** Intermediate buses that group related signals (e.g., all drums).
- **Auxiliary buses:** Separate paths for effects or monitor mixes.

Bussing provides flexibility and organizational control in complex mixes.

This page titled [4.7: The Mix Bus and Bussing](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.8: Routing and Signal Flow

Routing and Signal Flow

Routing is the process of sending signals to specific destinations. Signal flow describes the path audio takes through the system. Typical routing options include:

- Channel input → preamp → EQ → fader → mix bus.
- Auxiliary sends → external effects or monitor mixes.
- Direct outs → recording devices.

Understanding signal flow is fundamental for troubleshooting and creative flexibility.

This page titled [4.8: Routing and Signal Flow](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.9: Major Sections of a Mixer/Console

Major Sections of a Mixer/Console

Most mixers and consoles contain the following sections:

- **Input Section:** Microphone/instrument preamps, gain, and filters.
- **Channel Strip:** EQ, dynamics, auxiliary sends, pan, and fader.
- **Master Section:** Mix bus controls, subgroups, and overall output routing.
- **Auxiliary and Effects Section:** Manages monitor mixes and external processing.
- **Metering and Monitoring Section:** Visual and audible feedback of levels and routing.

With regards to the physical **input section** on most consoles/mixers, there will be an option between either a Mic connection (XLR) and/or a line-level connection (1/4" jack).

What is mic level?

A **mic-level or microphone-level signal** describes the voltage generated by a microphone when it picks up sound. Mic level is the weakest and **requires a pre-amplifier** to bring it up to line level. Microphone level is typically between -60 and -40 dB.

What is line level?

A **line-level signal** is approximately one volt, or about 1,000 times as strong as a mic-level signal, so the two do not ordinarily use the same input. This signal travels from your pre-amp to the amplifier that powers your speakers.

There are two standard line levels:

- -10 dB for consumer equipment (CD and DVD players)
- +4 dB for professional equipment (mixing consoles and effects units)

This page titled [4.9: Major Sections of a Mixer/Console](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.10: Broadcast vs. Production Consoles

Broadcast vs. Production Consoles

- **Broadcast consoles** prioritize reliability, quick access, and streamlined operation for live radio and television. They often include features like “on-air” muting, phone call integration, and fast routing. A broadcast console is typically a **split-section design**, with input, output, and monitoring functions separated for efficiency. These consoles also include assignment capability to **program output, monitor, and audition** channels, allowing operators to preview or cue material without sending it to the air feed.
- **Production consoles** (used in music and post-production) focus on flexibility, detailed signal shaping, and multi-track integration. A production console can provide **channels for many more sources** than a broadcast console. They include **submaster capability** in addition to extensive routing options, offering far greater flexibility. A production console is typically configured as an **in-line console**, where inputs, outputs, and monitoring functions are combined within the same channel strip, making it efficient for multi-track recording and mixdown.

Submasters

A **submaster** is a control that manages the overall level of a group of related channels, often referred to as a submix. Instead of adjusting each channel individually, the engineer can assign multiple channels—such as an entire drum kit, a horn section, or background vocals—to a single submaster fader. This allows the group to be balanced internally once and then controlled as a single unit within the overall mix.

Submasters provide flexibility by enabling engineers to:

- Maintain consistent balances within a group.
- Raise or lower the level of a section quickly.
- Apply processing or routing collectively to an entire group.

Channel Strip in a Production Console

A **channel strip** is the vertical section of a console dedicated to controlling one input signal. Each strip typically includes:

- An input preamp for gain control.
- EQ and filter sections for tonal shaping.
- Dynamics controls (compressors, gates, limiters).
- Auxiliary send knobs.
- Pan control.
- A fader.
- Routing buttons.

In **production consoles**, the channel strip is the building block of the system. Since they are often in-line, each strip contains both the input path (for recording) and the monitor path (for playback), streamlining workflow.

This page titled [4.10: Broadcast vs. Production Consoles](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.11: Features of Most Consoles

Features of Most Consoles

Most consoles, whether for broadcast, live sound, or production, share common features. Below are definitions and examples of the most important ones:

- **Input/Output Channel:** A signal path for connecting sources (microphones, instruments) into the console and routing them to outputs. Example: A vocal microphone connected to channel 1, routed to the main mix.
- **Input Selector:** Switches between different input types (mic, line, instrument). Example: Switching a channel from a line-level keyboard to a mic input.
- **Phantom Power:** +48V DC supplied through the mic input to power condenser microphones or active DI boxes. Example: Turning on phantom power for a studio condenser mic.
- **Mic Preamp:** Boosts low-level microphone signals to line-level for processing. Example: Increasing the gain for a quiet vocal performance.
- **Pad:** An attenuator switch that reduces signal level (commonly -10 to -20 dB) to prevent distortion from loud sources. Example: Engaging a pad when miking a snare drum.
- **Peak Indicator:** A light (usually red) that shows when a signal is close to clipping or distortion. Example: Adjusting mic gain when the peak light flashes.
- **Phase/Polarity Reverse:** Switches the polarity of a signal by 180°. Example: Fixing phase cancellation when two mics on a guitar amp are out of phase.
- **Panning:** Controls left/right positioning of a signal in the stereo field. Example: Panning guitars left and right for a wide mix.
- **EQ and Other Signal Processors:** Tone-shaping tools that adjust frequency content (bass, mid, treble) and dynamics processors like compressors. Example: Boosting vocal clarity with EQ.
- **Solo Button:** Isolates a channel so only that signal is heard in the monitor path. Example: Soloing the kick drum to fine-tune EQ.
- **Mute Button:** Silences a channel without changing its fader position. Example: Muting unused microphones during a performance.
- **Channel Faders:** Vertical sliders that set the relative volume of each input channel. Example: Adjusting lead vocals above background instruments.
- **Main Fader:** The master level control for the overall mix. Example: Raising the main fader to feed a PA system or recording device.

This page titled [4.11: Features of Most Consoles](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.12: The Audio Patchbay

The Audio Patchbay

A **patchbay** provides a centralized point for connecting and rerouting audio signals using patch cables. Instead of rewiring equipment directly, engineers can quickly change signal paths, integrate external processors, and troubleshoot systems. Patchbays are especially vital in large studios and broadcast facilities.

History of the Patchbay

Patchbays originated in the days of telephone switchboards, where operators manually routed calls using cords. The same principle was later adapted to audio and broadcast environments. In professional audio, patchbays often used **TT (tiny telephone) cables**, which became the standard because of their compact size, durability, and ability to fit many connections into a relatively small space. In addition to the TT patch cable, a larger ¼ inch patch cable can be found in most production studios.

Normal and Half-Normal Connections

Patchbays are often wired internally in one of two ways:

- **Normal:** The top and bottom jacks are internally connected (usually top = output, bottom = input). A signal flows automatically from the output to the input without any patch cable inserted. Plugging into either jack interrupts (or breaks) this internal connection, rerouting the signal.
- **Half-Normal:** The signal still flows from output to input internally, but patching into the output jack does not break the connection; instead, it splits the signal, allowing it to continue downstream while also sending a copy elsewhere. Inserting a cable into the input jack, however, breaks the internal connection.




Figure 4.12.1: “Patchbay”, by Justin De La Ornellas, (CC BY 2.0).

Input and Output Rows

Patchbays are typically arranged so that the **top row of jacks corresponds to outputs** (signals leaving a device), while the **bottom row corresponds to inputs** (signals entering a device). This top-to-bottom flow mirrors the natural direction of signal paths, making routing intuitive as signal typically flows from the top to the bottom.

The Goal of a Patchbay

The primary goal of a patchbay is to centralize all equipment connections so that **every input and output of all the equipment in a system is permanently connected to the rear of the patchbay**. This means the front panel serves as a flexible, accessible control point for routing signals without physically moving gear or replugging cables at the back of audio racks.

With this design, engineers can easily:

- Route microphones, instruments, and processors into different channels.
- Insert outboard gear into the signal chain.
- Split or reroute signals for creative or technical purposes.
- Quickly troubleshoot by testing connections at the patchbay.

This page titled [4.12: The Audio Patchbay](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.13: Automation

Automation

Modern consoles and DAW control surfaces often feature **automation**, allowing engineers to record and recall changes in fader levels, panning, and effects over time. Automation ensures consistency across multiple playbacks and enables detailed, dynamic mixes that would be impossible to perform manually in real-time.

Digital Console Automation

In digital systems, automation can be extended even further. **Digital consoles** are capable of fully automating nearly all functions, including:

- **Motorized Faders:** Physical faders that move automatically to reflect stored mix settings.
- **Controllable Rotary Knobs:** Rotary encoders that adjust EQ, dynamics, and other parameters, recalling precise settings instantly.
- **Computer/Software Integration:** Digital consoles can be controlled by computers or integrated with DAW software systems, allowing complete recall of sessions and settings.
- **Real-Time Recording of Mix Moves:** Fader movements, panning changes, and effect adjustments can be recorded in real time during a mix pass. These moves can later be edited with the same precision as any other computer data.

Automation in DAWs

Automation plays a **major role** in most software DAWs such as **Pro Tools, Logic, Cubase, and Ableton Live**. DAW automation allows engineers to:

- Draw or record automation curves for fader levels, panning, and plug-in parameters.
- Edit automation data with sample-level accuracy.
- Create dynamic, evolving mixes that change over time.

Automation in both digital consoles and DAWs provides unmatched flexibility and precision, transforming mixing from a manual, real-time process into a detailed, editable craft.

This page titled [4.13: Automation](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.14: DAW Control Surfaces

DAW Control Surfaces

In digital environments, DAW control surfaces replicate the layout of traditional mixers but control software parameters instead of analog circuits. They provide tactile control over virtual faders, knobs, and transport functions, bridging the gap between physical hardware and digital workflow.

This page titled [4.14: DAW Control Surfaces](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

4.15: Conclusion

Conclusion

Whether analog or digital, compact or large-scale, audio mixers and consoles form the backbone of sound production, broadcast, and live reinforcement. They provide the tools to balance, route, and shape signals, while DAW control surfaces extend these capabilities into the modern digital domain. Mastery of these tools allows engineers to transform raw sound into polished productions that meet both technical and artistic demands.

This page titled [4.15: Conclusion](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

CHAPTER OVERVIEW

5: Audio Recording

- [5.1: Introduction](#)
- [5.2: Digital vs. Analog](#)
- [5.3: Sample Rate](#)
- [5.4: Nyquist-Shannon Theory](#)
- [5.5: Bit Depth \(Resolution\)](#)
- [5.6: Quantization](#)
- [5.7: Binary Code](#)
- [5.8: Common Recording Systems](#)
- [5.9: The Digital Audio Workstation](#)
- [5.10: Audio Interface](#)
- [5.11: Digital Audio Connections](#)
- [5.12: Recording Media Types](#)
- [5.13: MIDI and Its Use](#)
- [5.14: Analog Audio Connectors](#)
- [5.15: Digital Audio Networking](#)
- [5.16: Conclusion](#)

This page titled [5: Audio Recording](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.1: Introduction

Introduction

The art and science of audio recording has transformed dramatically over the past century. From the earliest analog experiments with wax cylinders and magnetic tape to today's powerful digital workstations and networked audio systems, the goal has always been the same: to faithfully capture, reproduce, and manipulate sound.

In modern times, recording is no longer limited to large studios — it can happen anywhere, from professional facilities to home setups, classrooms, and even mobile devices. This popularization of technology has made an understanding of the **fundamentals of audio recording** more important than ever.

This chapter explores the essential elements of recording technology, including the differences between **analog and digital audio**, the role of **sample rate and bit depth** in recording, the principles of **quantization and binary storage**, and the tools that make it all possible — from **DAWs and audio interfaces** to **MIDI systems, connectors, and digital networking**. Along the way, it highlights the historical innovations that shaped the field and the modern practices that continue to define it.

By the end, you will see how the technical foundations of audio recording support not just the preservation of sound, but also its creative transformation — allowing artists, engineers, and producers to bring their ideas to life with clarity and precision.

This page titled [5.1: Introduction](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.2: Digital vs. Analog

Digital vs. Analog

Analog audio is a continuous electrical signal that directly represents sound waves. It captures every nuance but is subject to noise, distortion, and degradation over time (for example, tape hiss or vinyl wear).

Digital audio, on the other hand, represents sound as discrete numerical samples. This allows for cleaner storage, editing, and replication without quality loss, but depends heavily on proper sample rate, bit depth, and digital-to-analog conversion.

This page titled [5.2: Digital vs. Analog](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.3: Sample Rate

Sample Rate

The sample rate is the number of times per second that an analog signal is measured (sampled) to create a digital representation. Common sample rates include:

- **44.1 kHz** (CD audio standard)
- **48 kHz** (DVD standard)
- **96 kHz and above** (professional audio and archival work)

A higher sample rate captures more detail but requires more storage and processing power.

This page titled [5.3: Sample Rate](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.4: Nyquist-Shannon Theory

Nyquist-Shannon Theory

The **Nyquist-Shannon theorem** states that to accurately reproduce a sound, the sampling rate must be at least twice the highest frequency of the source audio. Since human hearing extends up to ~20 kHz, CD audio uses 44.1 kHz to ensure accurate capture with a little headroom.

Examples:

- A **1 kHz tone** requires a minimum of **2 kHz sampling rate**.
- A **10 kHz tone** requires at least **20 kHz sampling rate**.
- A **20 kHz tone** (upper limit of human hearing) requires at least **40 kHz sampling rate**.
- A system using **96 kHz sample rate** can capture frequencies up to **48 kHz**, providing extra bandwidth for processing and filtering.

This page titled [5.4: Nyquist-Shannon Theory](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.5: Bit Depth (Resolution)

Bit Depth (Resolution)

Bit depth determines the number of possible amplitude values for each sample. It directly affects the **dynamic range**, which is the difference between the **quietest** and **loudest** sounds a medium can reproduce without distortion or noise. A higher bit depth increases resolution, lowers the noise floor, and provides more headroom.

Dynamic Range Examples (Approximate Values)

- **Cassette tape:** ~60 dB
- **Vinyl record:** ~70 dB
- **16-bit digital audio (CD quality):** ~96 dB
- **24-bit digital audio (professional standard):** ~144 dB

Each increase of 1 bit adds roughly **6 dB** of dynamic range.

To determine the dynamic range of a digital signal, always multiply the bit depth by 6.

Bit Depth and Resolution

- **4-bit audio** – 16 possible levels (~24 dB range)
- **8-bit audio** – 256 possible levels (~48 dB range)
- **16-bit audio** – 65,536 possible levels (~96 dB range)
- **24-bit audio** – 16.7 million possible levels (~144 dB range)

Example of 4-bit audio (blue) superimposed over the (red) analog sound wave.




Figure 5.5.1: “4-bit resolution analog comparison”, Hyacinth, (CC BY-SA 4.0).

This page titled [5.5: Bit Depth \(Resolution\)](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.6: Quantization

Quantization

Quantization is the **process** of mapping the continuous range of an analog signal into discrete digital values defined by the bit depth. This introduces **quantization error**, perceived as a low-level noise floor. Higher bit depth reduces this error.

This can be confused with the term Quantize which is the action of working with MIDI performances and aligning the MIDI notes to a specific grid value. i.e. fixing a poorly played piano part and lining it up to the proper music beats/counts.

This page titled [5.6: Quantization](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.7: Binary Code

Binary Code

All digital audio is stored and transmitted as **binary code** (combinations of 0s and 1s). Each sample's amplitude is represented as a binary number, which allows for lossless reproduction, storage, and transfer of sound.

This page titled [5.7: Binary Code](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.8: Common Recording Systems

Common Recording Systems

- **Multitrack tape recorders** (analog legacy systems)
 - **Hard-disk recorders** (digital standalone recorders)
 - **DAWs (Digital Audio Workstations)** on computers
 - **Portable field recorders** for location recording
-

This page titled [5.8: Common Recording Systems](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.9: The Digital Audio Workstation

The Digital Audio Workstation (DAW)

A **DAW** is the central tool for modern recording. Popular examples include **Pro Tools, Logic Pro, Ableton Live, Cubase, and Reaper**.

DAWs allow:

- Multitrack recording
- Non-linear editing
- MIDI sequencing
- Audio processing with plugins
- Mixing and mastering in a single environment

Use in Post-Production

In film, television, and other media, DAWs play a vital role in **post-production**. They are used for:

- **Dialog editing** – cleaning, aligning, and processing recorded speech
- **ADR (Automated Dialogue Replacement)** – recording and syncing replacement lines to picture
- **Foley and sound effects editing** – recording or editing everyday sound effects for realism
- **Sound design** – creating or manipulating audio to match visuals or storytelling needs
- **Music scoring and synchronization** – composing and aligning music cues with visual events
- **Mixing for surround sound formats** such as 5.1, 7.1, or immersive formats like Dolby Atmos

DAWs in post-production provide powerful synchronization with video, timecode accuracy, and tools to prepare final deliverables for broadcast, cinema, or streaming platforms.

This page titled [5.9: The Digital Audio Workstation](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.10: Audio Interface

Audio Interface

An **audio interface** converts analog signals (microphones, instruments) into digital audio for the computer (analog to digital or A to D), and digital audio back into analog (digital to analog or D to A) for monitoring.

Key features include:

- Microphone preamps
- A/D and D/A converters
- Phantom power for condenser mics
- Input/output connections (RCA, XLR, TRS, digital I/O)

A **sound card** built into or attached to a computer functions in a similar way, but it is not designed for professional recording. Sound cards typically offer consumer-grade performance, whereas audio interfaces provide higher-quality converters, cleaner preamps, and more flexible connectivity.

Audio interfaces come in many sizes and configurations. Some are compact devices with only **one or two inputs and outputs**, while others are **large rack-mounted systems** that provide dozens of channels for professional studios, live sound, or broadcast applications.

This page titled [5.10: Audio Interface](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.11: Digital Audio Connections

Digital Audio Connections

Several formats transmit digital audio between devices:

- **S/PDIF** (consumer digital connection)
- **AES/EBU** (professional XLR-based digital)
- **ADAT (Lightpipe)** (8-channel optical transfer)
- **MADI** (multichannel professional format)

Importance of Digital Connections

Using a digital connection from one piece of equipment to another ensures that the signal remains in the **digital domain** without being converted back to analog. This prevents the introduction of **unwanted noise, interference, and distortion** that can occur with analog cabling, especially over longer distances.

Analog connections are more prone to problems such as **ground hum, cable capacitance, and signal loss**, while digital connections preserve audio with **bit-perfect accuracy** as long as the data is transmitted correctly.

Example of Equipment Benefiting from Digital Connections

A good example is a **digital mixing console connected to an external digital effects processor or recorder**. If both devices communicate digitally (for example, via AES/EBU or ADAT), the audio can be transferred **without any additional conversions**. This ensures pristine quality, maintains clock synchronization, and avoids the degradation that would come from repeated analog-to-digital and digital-to-analog conversions.

Word Clock and Its Importance

In a digital audio studio, every device must agree on **when** each sample occurs. This timing is controlled by a **word clock** — a master synchronization signal that ensures all devices in a system are locked to the same timing reference.

Without a shared word clock, digital devices can drift out of sync, causing **clicks, pops, jitter, or complete signal loss**. In a professional studio or live sound setup with multiple digital devices (interfaces, converters, digital consoles, effects units), one device is usually designated as the **master clock**, while the others act as **slaves** to that timing reference.

A stable, accurate word clock is **crucial for maintaining phase coherence and preventing digital artifacts**, especially in large systems where many channels of digital audio are transmitted simultaneously.

This page titled [5.11: Digital Audio Connections](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.12: Recording Media Types

Recording Media Types

- **Magnetic Tape** (analog legacy)
- **Optical Discs** (CD, DVD, Blu-Ray)
- **Hard Drives and SSDs** (standard today)
- **Flash memory** (SD cards in portable recorders)
- **Cloud storage** (collaboration and backup)

Optical Disc Storage Capacities

- **CD-R (Compact Disc Recordable)** – typically holds **700 MB – 800 MB** of data, or about **72–80 minutes of stereo audio**.
- **DVD (Digital Versatile Disc)** – holds **4.7 GB** on a single-layer disc (about 7 times the capacity of a CD) and **8.5 GB** on a dual-layer disc.
- **Blu-Ray Disc** – holds **25 GB** on a single layer and **50 GB** on a dual-layer disc, with newer versions exceeding **100 GB**.

CD History and 72-Minute Limit

The **Compact Disc (CD)** was introduced in **1982** by **Philips and Sony** as a digital replacement for vinyl records and cassette tapes. The CD's **44.1 kHz sample rate** and **16-bit resolution** were chosen to ensure full-range, high-quality stereo audio.

The disc was designed to hold **72 minutes of stereo audio** because Sony executive **Norio Ohga** insisted that a single CD should be able to contain the full performance of Beethoven's **Ninth Symphony**, one of the longest pieces in the standard classical repertoire. To achieve this, the disc diameter was set at **12 cm**, giving it enough capacity to store 650–700 MB of digital audio data.

This page titled [5.12: Recording Media Types](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.13: MIDI and Its Use

MIDI and Its Use

MIDI (Musical Instrument Digital Interface) is a protocol for transmitting musical performance data, not sound. It communicates:

- Notes, pitch, velocity
- Control changes (mod wheel, sustain pedal, volume)
- Synchronization data (Midi Time Code or MTC)

History of MIDI

MIDI was developed in the early **1980s** by a group of synthesizer manufacturers led by **Roland, Sequential Circuits, Yamaha, and Korg**. It was officially introduced in **1983** at the NAMM show, where two synthesizers from different companies successfully communicated with one another via MIDI.

The creation of MIDI solved a major problem in the music industry: before its adoption, instruments and devices from different manufacturers could not easily communicate. MIDI provided a **universal standard** for control, allowing musicians to connect various synthesizers, drum machines, sequencers, and later computers.

Music and Genres That Extensively Used MIDI

MIDI revolutionized the **1980s and 1990s** music landscape, particularly in genres like:

- **Electronic music** (synthpop, techno, house, trance)
- **Pop and rock** (integration of synthesizers and drum machines)
- **Film scoring** (virtual orchestration and sequencing)
- **Hip-hop and R&B** (samplers and MIDI drum machines became foundational tools)

MIDI made it possible for musicians to program complex arrangements, layer sounds, and synchronize multiple instruments with precision.

Relation to Modern Synthesizers

Modern synthesizers still rely heavily on MIDI. Whether hardware or software-based, they use MIDI data to trigger sounds, adjust parameters, and sync with DAWs. Virtual instruments (VSTs) inside DAWs also use MIDI to simulate anything from classic analog synths to full orchestras.

Examples of MIDI Instruments

- **E-Drums (Electronic Drum Kits)** – drum pads trigger sampled or synthesized drum sounds.
- **E-Guitars and MIDI Guitar Controllers** – convert string vibrations into MIDI data for triggering synths.
- **MIDI Keyboards/Controllers** – the most common, used to play virtual instruments.
- **MIDI Electronic Wind Instrument (EWI)** – simulate saxophones, flutes, or other wind instruments for electronic use.

MIDI Cables and Modern Connections

Traditionally, MIDI devices were connected using a **5-pin DIN MIDI cable**, with separate ports for **MIDI In, MIDI Out, and MIDI Thru**. These cables only transmit digital control data, not audio.

In modern setups, **USB connections** have largely replaced traditional MIDI cables. USB provides faster, bi-directional communication between instruments and computers, reducing the need for specialized interfaces. Many contemporary MIDI controllers (keyboards, drum pads, and wind controllers) connect directly to a computer or DAW via **USB**, while still offering the 5-pin DIN ports for compatibility with older hardware.

This page titled [5.13: MIDI and Its Use](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.14: Analog Audio Connectors

Analog Audio Connectors

Analog connectors carry continuous signals. They come in many shapes and sizes, each suited to a particular use in audio systems.

Common Analog Connectors

- **XLR** – balanced, professional microphones and equipment; 3-pin design reduces noise.
- **TRS (¼" balanced)** – Tip-Ring-Sleeve; used for professional line-level signals and headphones.
- **TS (¼" unbalanced)** – Tip-Sleeve; used for instruments such as electric guitars.
- **RCA (phono plug)** – common in consumer stereo and DJ equipment; unbalanced.

Additional Analog Connectors

- **TT (Tiny Telephone or Bantam Jack)** – a smaller version of the ¼" TRS, widely used in professional patch bays where space is limited.
- **Coaxial Connectors** – often used for both analog video and some audio; shielded cable helps reduce interference.
- **TRRS (Tip-Ring-Ring-Sleeve)** – a variation of the TRS connector with an extra ring, used for devices that carry stereo audio plus a microphone signal (common in smartphones and laptops).
- **1/8" (3.5 mm mini-jack)** – commonly used in portable audio devices, computers, and consumer headphones; can be TRS (stereo) or TRRS.
- **Speaker Wire (bare or with connectors)** – heavy-gauge unbalanced wire designed to carry amplified signals from a power amplifier to speakers.
- **Speaker Terminals (Binding Posts / Banana Plugs / Spade Lugs)** – used on amplifiers and speakers for secure connections with speaker wire.

This page titled [5.14: Analog Audio Connectors](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.15: Digital Audio Networking

Digital Audio Networking

Digital audio networking allows multiple channels of audio to be transmitted over computer networks. Standards include:

- **Dante** (widely used, Ethernet-based)
- **AVB** (Audio Video Bridging)
- **AES67** (open interoperability standard)

These systems simplify routing, reduce cabling, and allow for large-scale integration in studios, broadcast facilities, and live sound environments.

Older Systems: ISDN

Before modern IP-based networks became widespread, **ISDN (Integrated Services Digital Network)** was used in broadcast and remote audio links.

- ISDN offered relatively low-latency digital audio links over telephone lines, allowing broadcasters to connect remote studios or reporters with decent audio quality.
- Many ISDN codecs could carry stereo or multiple mono channels with compression, error correction, and synchronization.
- ISDN's bandwidth was limited compared to modern networks, so it typically used audio compression (e.g. ISDN codecs like Comrex, Tieline).
- ISDN has largely been supplanted by IP-based solutions (audio over Ethernet, streaming over the internet), but its legacy remains in broadcast infrastructure and transitional systems.

Streaming Audio and Over-IP Audio

Modern digital audio networking increasingly uses **streaming audio over IP** (Internet Protocol).

- **Protocols and Formats:** RTP, RTSP, HTTP Live Streaming, or proprietary systems (e.g. Dante over IP).
- **Codecs & Bitrates:** Compression (AAC, Opus) or uncompressed “studio” formats (AES67, WAV over IP).
- **Latency:** Must be minimized for live audio; influenced by network quality, buffering, and chosen protocol.
- **Quality & Reliability:** Requires error correction, packet recovery, and network prioritization (QoS).
- **Scalability:** A single source can feed multiple destinations; ideal for studios, live events, or cloud streaming.

Applications:

- **Live broadcasting** (concerts, talk shows, radio)
- **Remote collaboration** (distributed musicians and studios)
- **Large installations** (houses of worship, corporate AV, stadiums)
- **Cloud streaming services** (Spotify, Apple Music, YouTube, etc.)

This page titled [5.15: Digital Audio Networking](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

5.16: Conclusion

Conclusion

Audio recording has evolved from purely analog beginnings to a sophisticated digital landscape where precision, flexibility, and connectivity dominate. Understanding the fundamentals — from **sample rate, bit depth, and quantization** to the role of **DAWs, interfaces, and connectors** — is essential for anyone working with sound.

This page titled [5.16: Conclusion](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

CHAPTER OVERVIEW

6: The Microphone

- 6.1: Introduction
- 6.2: Transducer
- 6.3: Impedance
- 6.4: Dynamic vs. Condenser vs. Ribbon
- 6.5: Moving Coil Principle
- 6.6: Ribbon Mic Principle
- 6.7: Condenser Mic Principle
- 6.8: Microphone Construction
- 6.9: Directional Response
- 6.10: Frequency Response
- 6.11: Mic Limitations
- 6.12: Proximity Effect
- 6.13: Humbucker Coils in Microphones
- 6.14: Lavalier Mic Properties and Uses
- 6.15: Other Varieties of Mics
- 6.16: Wireless Mics
- 6.17: Microphone Accessories
- 6.18: XLR Cables
- 6.19: Conclusion

This page titled [6: The Microphone](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.1: Introduction

Introduction

Microphones are the gateway between the acoustic world and the realm of recorded sound. They serve as transducers, converting the physical vibrations of air into precise electrical signals that can be amplified, processed, or stored. Every type of microphone—whether dynamic, condenser, or ribbon—operates on distinct physical principles that influence its tone, sensitivity, and application. Understanding how microphones work, their construction, directional characteristics, and supporting accessories is essential for achieving professional-quality audio in any environment.

This page titled [6.1: Introduction](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.2: Transducer

Transducer

A microphone is a **transducer**, meaning it converts one form of energy into another. In this case, microphones transform acoustic energy (sound waves) into electrical signals. This principle allows sound to be captured, amplified, recorded, or transmitted.

This page titled [6.2: Transducer](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.3: Impedance

Impedance

Impedance is the effective resistance of an electrical circuit to alternating current (AC), measured in ohms (Ω). In microphones, impedance refers to how much the mic resists the flow of electrical signal.

- **Low Impedance (Low-Z):** Typically 150–600 Ω . These microphones are preferred for professional use because they allow long cable runs with minimal signal degradation and reduced noise. In essence the signal is difficult to “impede”.
- **High Impedance (Hi-Z):** Typically greater than 10k Ω . Found in many consumer and older microphones. Hi-Z mics are more susceptible to noise, signal loss, and reduced clarity, especially over long cables. These mics are easy to “impede”.

Importance of Impedance Matching

Impedance matching is critical for achieving the best signal transfer between a microphone and the device it’s connected to (such as a preamp, mixer, or recording device). If the microphone’s output impedance is too high compared to the input impedance of the device, signal loss, reduced frequency response, and added noise can occur. Professional audio gear is designed so that the input impedance is much higher (often 10x or more) than the microphone’s output impedance. This ensures **maximum voltage transfer, minimal distortion, and cleaner audio capture**.

This page titled [6.3: Impedance](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.4: Dynamic vs. Condenser vs. Ribbon

Dynamic vs. Condenser vs. Ribbon

- **Dynamic microphones:** Rugged, durable, no external power needed. Great for live sound and loud sources like drums or guitar amps.
- **Condenser microphones:** Sensitive and accurate, require phantom power (48V). Used in studios for vocals and instruments.
- **Ribbon microphones:** Use a thin metallic ribbon-like element suspended in a magnetic field. Known for warmth and smooth high-frequency response, ribbon mics have a naturally soft and vintage sound. They are often described as “dark” or “smooth” compared to the brightness of condenser mics. Classic ribbon microphones from the 1930s–1950s are considered rare, highly collectible, and prized for their unique tonal character. Modern ribbon designs have improved durability and can handle higher sound levels, but traditional vintage models remain fragile and are regarded as specialty microphones in professional studios.

This page titled [6.4: Dynamic vs. Condenser vs. Ribbon](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.5: Moving Coil Principle

Moving Coil Principle

Dynamic microphones operate on the **moving coil principle**. A diaphragm is attached to a coil of wire suspended in a magnetic field. When sound waves move the diaphragm, the coil moves, inducing a current proportional to the sound. The term “dynamic” is used as the voice coil is moving, or is “in motion” as sound waves strike the diaphragm.

Illustration of the Moving Coil Principle:




Figure 6.5.1: “Mic-dynamic”, [Banco](#), ([CC BY-SA 3.0](#)).

1. Sound waves
2. Membrane/diaphragm
3. Coil
4. Magnet
5. Signal

This page titled [6.5: Moving Coil Principle](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.6: Ribbon Mic Principle

Ribbon Mic Principle

Ribbon microphones use a thin corrugated aluminum ribbon (looks like ribbon you might see on a birthday present) placed between magnetic poles. Unlike dynamic and condenser designs, **there is no diaphragm** — the ribbon itself both detects and generates the signal. Sound waves move the ribbon directly, causing it to vibrate within the magnetic field and produce an electrical signal.

Most ribbon microphones are considered a type of **dynamic microphone**, since they operate by electromagnetic induction and require no external power. However, there are **active ribbon microphones** that include internal electronics, requiring phantom power to provide a stronger output signal and more consistent performance.

A critical consideration is that **older ribbon microphones can be damaged by phantom power** if accidentally applied. The thin ribbon element is extremely delicate and may burn or stretch under voltage. Modern ribbon microphones often include protective circuitry or designs that allow safe phantom power use, but vintage models should always be handled with care.

This page titled [6.6: Ribbon Mic Principle](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.7: Condenser Mic Principle

Condenser Mic Principle

Condenser microphones, also known as **capacitor microphones**, use a diaphragm (front plate) mounted close to a backplate, forming a capacitor. Between these two plates is **dielectric material**, which allows capacitance to change as the diaphragm moves. When sound waves hit the diaphragm, the spacing and dielectric properties shift, causing fluctuations in capacitance that generate the microphone's signal.

Because the signal from a condenser (capacitor) capsule is extremely low-level, these microphones require an external source of power to operate. This is commonly provided through **phantom power**, which is a DC voltage (typically 48 volts) applied to the microphone through its connecting cable.

Phantom Power Sources

- **Mixing consoles or audio interfaces:** Phantom power is often supplied directly through the **XLR cable** from the console or preamp.
- **Internal batteries:** Some condenser microphones require a battery in order to operate.
- **External power supplies:** Certain high-end or vintage condenser mics use dedicated power units which are plugged into an AC wall outlet.
- **USB condenser microphones:** In this case, phantom power is provided by the **computer itself through the USB cable**.

Types of Condenser Microphones

There are two main types of condenser microphone capsules:

- **Externally polarized condensers:** These rely on phantom power (or another external supply) to charge the capacitor element. They are highly sensitive and common in professional studio microphones.
- **Pre-polarized condensers (Electret microphones):** These have a permanent charge built into the capsule material so there is no need for external phantom power. They are generally smaller, more affordable, and commonly found in lavaliers, headsets, and consumer electronics. Despite being compact, electret mics can offer excellent performance in many applications.

This combination of a movable diaphragm, dielectric material, and powering system (phantom power) allows condenser mics to deliver the high sensitivity and broad frequency response that make them a standard choice in studios and professional recording environments.

This page titled [6.7: Condenser Mic Principle](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.8: Microphone Construction

Microphone Construction

Most microphones have:

- **Diaphragm** (thin mylar membrane)
- **Transducer element** (coil, ribbon, or capacitor plate)
- **Protective housing** (casing)

Output connector (XLR, USB, etc.)

This page titled [6.8: Microphone Construction](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.9: Directional Response

Directional Response (Polar Pickup Patterns)

A **polar pickup pattern** describes how a microphone responds to sounds coming from different directions around its capsule. In other words, it shows the areas where the microphone is most sensitive and the areas where it rejects sound. Understanding polar patterns is essential, since **all microphones have unique directional responses**, and choosing the wrong mic for the job can lead to unwanted noise, feedback, or poor isolation of the desired sound source.

We call a microphone's pickup pattern a "**polar pattern**" because the graphical representation of the microphone's sensitivity to sound from different directions forms a circle or "polar" shape, with the center representing the microphone and the circumference depicting sound at various angles. The term "polar" refers to this polar coordinate system used to map the sound pickup in a 360-degree field around the mic.

- **Omnidirectional:** Picks up sound equally from all directions.
- **Cardioid:** Heart-shaped pattern; focuses on the front, rejects rear sound.
- **Supercardioid:** Tighter forward focus, with some rear pickup.
- **Hypercardioid:** Even narrower than supercardioid, with a slightly larger rear lobe.
- **Ultracardioid:** Extremely focused pickup in the front, with more pronounced sensitivity directly behind the mic.
- **Bidirectional (Figure-8):** Captures sound from front and back, rejects sides.

Any pickup pattern **other than omnidirectional is considered unidirectional**, meaning it favors sound from one primary direction.

How Directional Response Works

Directional microphones rely on **acoustic ports** in the mic body that allow sound to enter at different points, creating phase differences that reinforce or cancel sound from certain directions. Importantly, directional response is also **frequency dependent**:

- At **low frequencies**, directional patterns are broader and less focused.
- At **higher frequencies**, microphones become more directional, narrowing their pickup pattern.




Figure 6.9.1: "Microphone", [Galak76](#), (CC BY-SA 4.0).

This page titled [6.9: Directional Response](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.10: Frequency Response

Frequency Response

Each microphone has a **frequency response curve**, showing how it reacts across frequencies. Flat responses are best for accurate recordings, while shaped responses may boost certain ranges (like vocal presence). However, the majority of microphones will not have a flat response. Instead each mic will do better with certain frequencies. This is shown on a frequency response curve graph as shown below.




Figure 6.10.1: “Oktava319vsshuresm58”, [Gmaxwell](#), (CC BY-SA 3.0).

To reiterate, **low frequencies tend to have an omnidirectional response**, meaning they spread out and are captured more evenly from all directions. **High frequencies are much more directional**, creating a narrower pickup pattern. This principle is critical to understand because it directly affects how microphones capture different sounds in real-world environments.

This page titled [6.10: Frequency Response](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.11: Mic Limitations

Mic Limitations (Distortion)

Microphones have limits and can become distorted when exposed to very loud sound sources that exceed their maximum sound pressure level (SPL). This distortion can result in harshness, clipping, or an inaccurate representation of the sound.

Pad Switch

To manage this, many microphones (particularly condenser mics) include a built-in **pad switch**. A pad reduces the microphone's output level by a fixed amount, such as **-10 dB** or **-20 dB**, before it reaches the preamp. By lowering the output signal, the pad prevents overloading either the microphone's internal electronics or the connected equipment.

- The **pad switch** may be built directly into the microphone's body.
- Alternatively, a pad switch/button may be located on a **mixing console** or a **mic preamp**.

The more sensitive a microphone is, the louder its output will be, which increases the risk of overload when capturing loud sources like drums, brass instruments, or amplified guitars.

Signal-to-Noise Ratio (S/N)

Microphones also have a **signal-to-noise ratio (S/N)** rating. This measurement compares the strength of the desired audio signal to the level of background noise inherent in the microphone's circuitry. The signal-to-noise ratio is always expressed in decibels. The higher the decibel the better the ratio.

- A **higher S/N ratio** means the microphone delivers a clearer signal with less self-noise.
- A **lower S/N ratio** indicates that the microphone's internal noise may be more noticeable, especially in quiet recordings.

The S/N ratio is critical in professional recording, as it determines how clean and transparent the microphone will sound, particularly in high-fidelity environments.

This page titled [6.11: Mic Limitations](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.12: Proximity Effect

Proximity Effect

Directional microphones exhibit a **proximity effect**, where low frequencies are boosted when the sound source is close. Singers sometimes use this creatively, but it can cause muddiness if uncontrolled.

Bass Roll-Off Switch

To help compensate for the low-frequency build-up caused by the proximity effect, some microphones include a **bass roll-off switch**. This feature reduces low-frequency sensitivity, effectively filtering out unwanted rumble, stage noise, or excessive bass. The switch works by engaging a **high-pass filter**, which allows higher frequencies to pass through while attenuating lower ones.

- On many microphones, this switch is built directly into the mic body.
- Some **mixing consoles** or **preamps** also include a bass roll-off (or high-pass filter) switch.

For example, a bass roll-off may reduce frequencies from **70 Hz and below**, which helps eliminate subsonic noise, handling vibrations, or unwanted bass buildup, while preserving clarity in vocals and instruments.

This page titled [6.12: Proximity Effect](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.13: Humbucker Coils in Microphones

Humbucker Coils in Microphones

Some microphones use **humbucker coils** to reduce electromagnetic hum. The design works by using two coils wound in opposite directions, which cancels out noise from electrical interference, similar to humbucker pickups used in electric guitars.

The humbucker coil is specifically designed to reduce or eliminate the **50–60 Hz cycle hum** caused by alternating current (AC) power systems. This type of interference can easily be picked up by microphone wiring and coils, especially in environments with lots of electrical equipment.

Humbucker coils are most commonly found in **dynamic microphones**, where their ability to suppress AC hum is particularly valuable in live sound and studio environments.

This page titled [6.13: Humbucker Coils in Microphones](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.14: Lavalier Mic Properties and Uses

Lavalier Mic Properties and Uses

Lavalier microphones are small clip-on mics, often omnidirectional. They are widely used in film, broadcast, theater, and presentations, providing discreet, hands-free sound capture.

This type of microphone typically **boosts high frequencies** to enhance vocal clarity and intelligibility, compensating for the placement on clothing rather than directly in front of the mouth. Lavalier mics are most often **electret-type condenser microphones**, which makes them compact, lightweight, and easy to conceal.

Most **TV broadcasters** use lavalier mics clipped to their collar or lapel, commonly connected to a **bodypack transmitter** as part of a wireless system, giving them freedom of movement while maintaining consistent audio quality.

This page titled [6.14: Lavalier Mic Properties and Uses](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.15: Other Varieties of Mics

Other Varieties (Highly Directional) of Mics

Shotgun Microphones

Shotgun mics use an interference tube to achieve a highly directional pickup. They're ideal for film and field recording, focusing on distant sound sources while rejecting off-axis noise.

Contact Microphones

Contact mics pick up vibrations from solid surfaces instead of air. Often used for acoustic instruments, they can be attached directly to a body of wood, glass, or metal.

Parabolic Microphones

These use a **parabolic dish** to focus sound waves onto a microphone at the focal point. Common in sporting events, nature recordings, and surveillance, they can capture sounds from long distances.

Headset Microphones

Headset mics combine a microphone with headphones. They allow mobility and are used by performers, broadcasters, and call center workers. Their close positioning provides consistent sound levels.

Boundary Microphones

Also known as **PZM (Pressure Zone Microphones)**, these are placed on flat surfaces to capture sound reflections. They are effective for conference rooms, stages, and theatrical productions.

Stereo Microphones

Stereo microphones contain two capsules arranged for different pickup techniques (X/Y, A/B, Mid-Side). They create a stereo image in one unit, making them useful for location and field recordings.

USB Microphones

USB microphones include an internal preamp and digital converter. They connect directly to computers without external audio interfaces, making them popular for podcasts, streaming, and home studios.

Multidirectional Microphones

These mics can switch between polar patterns (omni, cardioid, figure-8, etc.), offering flexibility for different recording situations. They are usually found in higher-end condenser mics.

This page titled [6.15: Other Varieties of Mics](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.16: Wireless Mics

Wireless Microphones

Wireless microphones, also known as **radio mics**, **FM mics**, **transmitter mics**, or **cordless mics**, allow performers, speakers, and broadcasters to move freely without being tethered by cables.

Wireless systems work by converting the microphone's signal into a radio frequency transmission. This is sent to a **receiver**, which outputs the audio directly to a mixing console or audio interface.

- A **standard wired microphone** can be converted into a wireless mic by attaching a transmitter to its rear, allowing it to transmit wirelessly.
- **Handheld wireless microphones** have a built-in transmitter within the mic body.
- **Miniature and headset microphones** typically connect to a **bodypack transmitter**, which clips to the belt or pocket and transmits the signal wirelessly.

Wireless microphones can operate over a wide range, from about **100 feet to as far as 2,500 feet**, depending on the system's power, frequency band, and environment.

Interference Considerations

One of the challenges of wireless systems is **transmission interference**. Wireless mics share frequency ranges with other radio devices, and crowded RF environments (such as concerts, broadcasts, or urban areas) can lead to dropouts, noise, or signal loss. Professional-grade wireless systems often include frequency agility, diversity reception, and encryption to reduce interference and ensure reliable performance.

This page titled [6.16: Wireless Mics](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.17: Microphone Accessories

Microphone Accessories

Stands

- **Straight stands:** Upright, stage use.
- **Boom stands:** Adjustable arms for angled placement.
- **Desk stands:** Compact, for podcasts and broadcasting.
- **Gooseneck stands:** Flexible, common at lecterns.
- **Fish pole (boom pole):** Used in film to position shotgun mics overhead. This piece of equipment was invented by director Dorothy Arzner in 1929 during her work on the film “The Wild Party”. She used a fishing pole to hold the mic over the head of the actors in order to capture the dialog.

Popper Stoppers (Pop Filters)

Reduce plosives (“P” and “B”) by diffusing air.

Made of a **frame**, **mesh or nylon screen**, and a **mounting arm/gooseneck**.

Windscreens and Dead Cats

- **Foam windscreens:** Reduce the sounds caused by wind and moving air.
- **Dead cat (furry wind-shield):** A long-haired synthetic cover placed over a foam windscreen, used in outdoor recording to drastically reduce the sound of wind. Its furry texture slows and disperses air movement before it reaches the mic capsule, making it essential for field production and film sets.

Shock Mounts and Mic Cradles

- **Shock mounts:** Specialized mounts that suspend a microphone in elastic bands or rubberized systems to isolate and decouple it from mechanical vibrations, handling noise, or stand bumps. They are essential for studio condensers, which are very sensitive to vibration.
- **Mic cradles:** A variation of the shock mount that securely holds the mic in place while providing additional suspension or swivel flexibility. These are often used in broadcast environments or with larger studio microphones.

This page titled [6.17: Microphone Accessories](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.18: XLR Cables

XLR Cables

The **XLR connector** is the professional standard for microphones. It provides a **balanced** connection that reduces noise and interference. XLR cables are durable and designed for long cable runs without signal loss.

An XLR connector is typically a **3-pin connector**, sometimes referred to as a **Cannon plug** after its original inventor, James H. Cannon, founder of Cannon Electric (later purchased by ITT). The term “XLR” comes from the Cannon series that featured a latch (**L**) and rubber insulation (**R**).

The 3 pins are standardized as follows:

- **Pin 1:** Ground (shield)
- **Pin 2:** Hot (+, non-inverting)
- **Pin 3:** Cold (–, inverting return)

This balanced wiring helps cancel noise and interference over long cable runs, making XLR the preferred connector for professional audio.

There are two physical types of XLR connections:

- **Male connectors:** Found on microphones and equipment outputs. They have 3 exposed pins.
- **Female connectors:** Found on cables and equipment inputs. They have 3 recessed holes that accept the male pins.

This male-to-female design ensures a secure, noise-resistant connection and makes it impossible to connect them incorrectly.

This page titled [6.18: XLR Cables](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

6.19: Conclusion

Conclusion

Microphones are essential tools that bridge the acoustic world with the electronic. From simple transducers to sophisticated condenser designs, microphones capture sound in countless ways—tailored for studios, live performances, broadcasting, and creative experimentation. Understanding their principles, types, and accessories helps engineers and performers achieve the best possible sound quality.

This page titled [6.19: Conclusion](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

CHAPTER OVERVIEW

7: Speakers and Headphones

- [7.1: Introduction](#)
- [7.2: The Audio Signal Chain](#)
- [7.3: Speaker Function](#)
- [7.4: The Speaker as a Transducer](#)
- [7.5: Types of Speakers](#)
- [7.6: Drivers and Frequency Bands](#)
- [7.7: Speaker Cabinet Design and Construction](#)
- [7.8: Active vs. Passive Speakers](#)
- [7.9: Polarity and Phase](#)
- [7.10: Crossover Networks](#)
- [7.11: Bi-Amplification](#)
- [7.12: Power Amplifiers](#)
- [7.13: Characteristics of Monitoring Systems](#)
- [7.14: Monitoring Systems- Stereo and Mono](#)
- [7.15: Headphones](#)
- [7.16: Headphone Monitoring in Studios](#)
- [7.17: Conclusion](#)

This page titled [7: Speakers and Headphones](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.1: Introduction

Introduction

Understanding how we hear reproduced audio requires exploring the systems that convert electrical signals into sound waves. Speakers and headphones play a crucial role in audio reproduction, bridging the gap between electronic signals and human perception. This chapter examines the design, function, and characteristics of these listening systems.

This page titled [7.1: Introduction](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.2: The Audio Signal Chain

The Audio Signal Chain

The audio signal chain begins with the source—whether that’s a microphone, instrument, or playback device—and moves through processing stages such as mixing consoles, amplifiers, and effects units. At the end of the chain, the **speaker (also referred to as a monitor)** serves as the **final link** in this signal path.

The quality of the audio we perceive is influenced not only by the **speaker itself** but also by the **listening environment**. Both should be optimized to achieve the most accurate and faithful representation of the original sound. Even the highest-quality speaker can be compromised by poor room acoustics, while a well-treated space with carefully placed monitors allows for precise and reliable listening.

This page titled [7.2: The Audio Signal Chain](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.3: Speaker Function

Speaker Function (Monitor)

A **monitor speaker** is designed to reproduce audio as accurately as possible without coloration. Studio monitors differ from consumer hi-fi speakers because they aim for a “flat” response, enabling audio engineers to hear a true representation of the sound during recording, mixing, and mastering.

This page titled [7.3: Speaker Function](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.4: The Speaker as a Transducer

The Speaker as a Transducer

Speakers are **electroacoustic transducers**. They convert electrical energy into mechanical energy (vibrations of a diaphragm) and then into acoustic energy (sound waves in the air). This conversion is fundamental to all speaker and headphone designs.

In a way, a **microphone and a speaker have much in common**, as they are both transducers. The mechanics of both devices are very similar—most notably in **moving-coil (dynamic) designs** where a diaphragm and a voice coil interact with a magnetic field. Because of this similarity, a microphone can actually function as a crude speaker, though it is not designed for that purpose. Conversely, a speaker can serve as a microphone by generating an electrical signal when its diaphragm is moved by sound waves.

While this crossover is not typically used in practice, there are specific applications where a speaker is intentionally designed or repurposed as a microphone. One example is the **Subkick**, a type of bass drum microphone that uses a speaker element to capture extremely low-frequency energy. The Subkick resembles a small speaker placed in front of the drum, but instead of producing sound, it outputs a microphone signal, effectively capturing the deep resonance of the bass drum.

This page titled [7.4: The Speaker as a Transducer](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.5: Types of Speakers

Types of Speakers

Moving Coil (Dynamic)

The most common type, using a voice coil attached to a diaphragm. When electrical current flows through the coil, it interacts with a magnetic field, causing the diaphragm to vibrate.

Most **recording studios and mixing rooms** rely on this type because it offers reliability, accurate response, and durability.

Electrostatic

Uses a thin, electrically charged diaphragm suspended between two conductive plates. They deliver exceptionally clear and detailed sound but require external power supplies.

Electrostatic speakers are typically found in **higher-end stereo systems** used by **audiophiles**—people who deeply appreciate the nuances of **high-fidelity audio reproduction**.

Ribbon

Employs a thin ribbon of metal suspended in a magnetic field. Ribbon speakers are prized for natural high-frequency response but are fragile and less efficient.

This page titled [7.5: Types of Speakers](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.6: Drivers and Frequency Bands

Drivers and Frequency Bands

No single driver can reproduce the entire frequency spectrum.

- **Woofers** handle low frequencies.
- **Midrange drivers** reproduce middle frequencies.
- **Tweeters** handle high frequencies.

In large systems, **subwoofers** extend bass response, while **super-tweeters** handle the extreme highs.

The term **driver** is derived from the ability of the speaker to *drive air*—that is, to move air molecules back and forth. This movement creates the pressure variations that our ears interpret as sound waves.

To better understand how a driver works, it is helpful to see a **cutaway diagram of a speaker cone**:




Figure 7.6.1: “Loudspeaker-bass”, [Syjo](#), (CC BY-SA 3.0)

1. **Big Magnet** (the magnetic structure that drives motion).
2. **Voice coil** (the wire coil that interacts with the magnet to move the cone).
3. **Spider and Surround**(the suspension that centers the voice coil and allows controlled movement).
4. **Cone** (the diaphragm that vibrates the air)

This page titled [7.6: Drivers and Frequency Bands](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.7: Speaker Cabinet Design and Construction

Speaker Cabinet Design and Construction

Cabinets control the movement of air and vibrations. Key designs include:

- **Sealed (acoustic suspension):** tight bass but less efficient.
- **Ported (bass reflex):** uses tuned vents for extended low end.
- **Transmission line and horn-loaded:** advanced designs offering higher efficiency.

Construction materials (wood composites, plastics, metals) influence resonance, coloration, and durability.

Most speaker cabinets will **house multiple drivers**, each handling different parts of the frequency spectrum. A **3-way speaker** means there are **three separate drivers** in the cabinet (typically a woofer, midrange, and tweeter). A **2-way speaker** contains **two drivers** (usually a woofer and tweeter). The number of drivers corresponds directly to the speaker's ability to divide and reproduce the frequency spectrum more accurately.

This page titled [7.7: Speaker Cabinet Design and Construction](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.8: Active vs. Passive Speakers

Active vs Passive Speakers

- **Passive speakers** require an external amplifier. They are lighter but need more setup.
- **Active speakers** include built-in amplifiers, matched to the drivers and crossovers. They simplify connections but are heavier and more expensive.

Pros and Cons:

- Active = convenience, accuracy, portability trade-offs.
- Passive = flexibility, upgradeability, but requires careful amplifier matching.

Active speakers may also include **various EQ and volume controls**, since active electronics are incorporated directly into the design. This allows for fine-tuning the sound to match the room or listening preferences.

Passive speakers, on the other hand, typically only have an **input connection**—often wire terminals or another simple connector—because all of the signal processing and amplification happens externally.

This page titled [7.8: Active vs. Passive Speakers](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.9: Polarity and Phase

Polarity and Phase

- **Polarity:** the positive/negative alignment of wiring. Incorrect polarity causes phase cancellation.
- **Phase:** time alignment of sound waves from multiple drivers or speakers. Misaligned phase reduces clarity, weakens bass, and alters stereo imaging.

Wiring a speaker is done by connecting the **positive terminal to the positive connection** and the **negative terminal to the negative connection**. Both speakers in a stereo setup must be wired identically. If one speaker is wired incorrectly (positive to negative and vice versa), polarity problems will occur, causing serious phase cancellation and producing very poor audio quality.

This page titled [7.9: Polarity and Phase](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.10: Crossover Networks

Crossover Networks

A **crossover** divides the incoming signal into frequency bands for different drivers.

- **Passive crossovers** use resistors, capacitors, and inductors inside the speaker.
- **Active crossovers** split the signal before amplification, offering more precision and efficiency.




Figure 7.10.1: “Crossover Networks”, GDunbar, (CC BY-SA 4.0).

To reiterate, since a **single speaker driver cannot reproduce the entire range of audible frequencies**, separate drivers are employed to handle specific bands of the spectrum. For example, woofers reproduce low frequencies, tweeters handle high frequencies, and midrange drivers cover the middle band. The crossover ensures that each driver receives only the frequencies it is designed to reproduce, resulting in a more accurate and balanced sound.

This page titled [7.10: Crossover Networks](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.11: Bi-Amplification

Bi-Amplification

Bi-amping uses separate amplifiers for different frequency ranges (e.g., lows and highs). Large venues often employ **tri-amping** or more, ensuring maximum clarity and power distribution in concert sound systems.

Bi-amping can also **increase the overall efficiency** of a monitoring system. By dedicating separate amplifiers to different frequency ranges, the amplifiers are not forced to handle the full spectrum of audio, which reduces strain. This design helps to **reduce intermodulation distortion**—the unwanted interaction of multiple frequencies within a single amplifier stage—and results in **improved sound quality** with greater clarity and detail.

When using an **active crossover network** in a bi-amp setup, the frequencies are separated **before** they reach the amplifiers. The audio from a console first passes through an **active (electronic) crossover**, which divides the signal into specific frequency bands (e.g., lows and highs). Each frequency band is then sent to its own dedicated amplifier. Finally, the outputs of the amplifiers are connected directly to the drivers (woofers, tweeters, etc.), ensuring that each driver only receives the frequencies it is designed to reproduce. This arrangement provides maximum efficiency, precision, and control.

This page titled [7.11: Bi-Amplification](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.12: Power Amplifiers

Power Amplifiers

Amplifiers provide the electrical energy required to drive speakers. Key considerations include:

- Wattage output
- Impedance matching
- Headroom and distortion levels
- Modern amps are solid-state (light, efficient) or tube-based (warm, musical).

Power amplifiers are also needed to provide **sufficient power so that the signal does not clip**. Clipping occurs when the amplifier is pushed beyond its maximum capability, creating distortion that can damage both the sound quality and the speakers themselves.

It is also important to note that a **3 dB increase in sound level requires twice as much amplifier power**. This exponential relationship between sound pressure level (SPL) and amplifier wattage highlights the importance of selecting an amplifier with enough headroom to handle peaks in the audio signal without distortion.

This page titled [7.12: Power Amplifiers](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.13: Characteristics of Monitoring Systems

Characteristics of Monitoring Systems

Monitoring systems must reproduce sound as accurately and consistently as possible so that audio engineers and listeners can make reliable judgments. Several key characteristics determine their performance:

Frequency Response

An ideal monitoring system has a **flat frequency response**, meaning it reproduces all frequencies evenly without boosting or cutting specific ranges.

Coverage and Polar Response

Monitoring systems should provide **consistent coverage** across the listening area. Polar response describes how evenly a speaker projects sound in different directions:

- **Narrow patterns** focus sound but limit coverage.
- **Wide patterns** cover more area but may reduce precision.

Sensitivity and Output Level

- **Sensitivity** measures how loud a speaker gets from a given input, usually expressed as dB SPL at 1 watt/1 meter.
- **Power handling (watts)** defines the maximum safe amplifier power. High sensitivity speakers require less power, while low sensitivity designs need stronger amplifiers.

Distortion

Different types of distortion can affect monitoring accuracy:

- **Harmonic distortion:** unwanted harmonics added to the signal. It is typically expressed as a **percentage of the total signal**, known as **THD (Total Harmonic Distortion)**. Lower THD values indicate cleaner, more accurate sound reproduction.
- **Intermodulation distortion:** interaction between multiple frequencies.
- **Mechanical distortion:** caused by driver or cabinet limitations.
- **Overload distortion:** from overpowering amplifiers or clipping.
- **Transient distortion:** occurs when a speaker has difficulty reacting to a **rapidly changing signal**. This delay in response can create a **ringing effect**, where the sound continues briefly after the signal has stopped, reducing clarity and accuracy.

Arrival Time and Phase

Sound waves from different speakers can arrive at slightly different times, especially in large sound systems. Misaligned timing causes phase issues, smearing the stereo image and reducing clarity.

- In live sound, **digital delay units** are used to synchronize arrival times across multiple speakers.
- In studios, proper placement ensures phase coherence at the listening position.

Studio Speaker Placement

The most effective arrangement is the **equilateral triangle setup**—two monitors and the listener form equal sides of a triangle. Monitors should be:

- Placed at **ear level**
- Decoupled from surfaces to minimize reflections
- Angled toward the listening position for accurate imaging
- Positioned away from boundaries: keeping monitors **1 to 2 feet away from walls and ceilings** prevents certain frequencies (especially low frequencies) from being **artificially enhanced** by reflections and boundary effects. This spacing helps maintain a more natural, accurate response in the listening position.

Near Field, Mid Field, and Far Field Monitors

- **Near field monitors:** placed close to the listener, they minimize the influence of room acoustics and reflections, making them common in smaller studios.
- **Mid field monitors:** positioned farther away, they provide greater output and are used in medium to large control rooms.
- **Far field monitors:** large, powerful monitors often built into studio walls. They deliver high volume levels and extended bass, allowing engineers to evaluate how mixes translate to larger playback environments.

This page titled [7.13: Characteristics of Monitoring Systems](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.14: Monitoring Systems- Stereo and Mono

Monitoring Systems: Stereo and Mono

Stereo sound is **two-dimensional**. It has:

- **Width (left to right)** – how sounds are placed across the horizontal field.
- **Depth (front to back)** – how sounds are perceived in terms of distance and spatial layering.

Stereo listening requires **two speakers placed symmetrically** in the room, usually forming an **equilateral triangle** with the listener at the third point. When properly configured, the monitoring system can **accurately represent the position of each sound element** in the stereo field of a recording, allowing instruments, voices, and effects to be placed with clarity and balance. This is essential in professional mixing, as it ensures that the intended placement of sounds translates correctly to other playback systems.

Mono monitoring, by contrast, collapses the sound field into a **single channel**. This is important for checking **phase compatibility** and ensuring that all elements of a mix remain balanced and audible when reduced to one channel—still common in certain broadcast or portable listening environments.

Some studios also employ **surround monitoring systems** for film, television, and immersive audio formats, expanding the sound field beyond stereo.

This page titled [7.14: Monitoring Systems- Stereo and Mono](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.15: Headphones

Headphones

Properties

Headphones are personal transducers, offering isolation and direct monitoring.

- **Frequency response** should be **wide, flat, and uncolored** so that the reproduction is as accurate as possible.
- The **listener or engineer must be familiar with the sonic characteristics** of the headphones, since every model has its own subtle coloration.
- Frequency response varies by design, and impedance affects power requirements.

Headphones that **go over the ears** are called **circumaural**. They provide full coverage around the ear and generally offer better isolation and comfort for extended listening compared to smaller designs.

In-Ear vs Over-Ear

- **In-ear monitors (IEMs)**: portable, isolating, used in live performances.
- **Over-ear headphones (circumaural)**: comfortable, extended response, often used in studios.

Pros and Cons:

- In-ear: isolation, portability, but limited comfort for long use.
- Over-ear (circumaural): natural soundstage, comfort, but bulkier and less isolating from outside noise.

This page titled [7.15: Headphones](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.16: Headphone Monitoring in Studios

Headphone Monitoring in Studios

Headphones play an important role in the recording and mixing process, but they must be used with care and understanding. While they provide **intimate and detailed listening**, they differ from speakers in how they present the stereo image and frequency response.

Advantages of Headphone Monitoring

- **Isolation:** Headphones eliminate room acoustics, making them ideal in untreated or noisy environments.
- **Detail:** Subtle noises, edits, and artifacts can often be heard more clearly in headphones.
- **Portability:** Engineers can work consistently across different environments with a familiar set of headphones.
- **Tracking:** Performers use headphones while recording to monitor backing tracks or click tracks without sound bleeding into microphones.

Limitations of Headphone Monitoring

- **Stereo Image:** Headphones present sound **directly into each ear**, which creates an exaggerated separation (hard left/right) and removes the natural crossfeed that occurs when listening to speakers. This can make mixes sound unrealistic when played back on speakers.
- **Bass Perception:** Low frequencies may be misleading in headphones, either exaggerated or lacking, depending on the design.
- **Fatigue:** Long sessions on headphones can cause ear fatigue more quickly than speakers.

Best Practices

- **Cross-check mixes:** Always compare headphone mixes on speakers to ensure balance translates across systems.
- **Familiarity:** Engineers should spend time learning the sonic “signature” of their headphones, just as they do with monitors.
- **Use both tools:** The most accurate results come from combining **speaker monitoring** for spatial judgment and **headphone monitoring** for detail work.
- **Mono checks:** Listening in mono on headphones helps reveal phase problems that might be masked in stereo playback.

In professional studios, headphones are treated as a **secondary reference**, while speakers remain the **primary monitoring system**. Together, they provide a more complete and reliable picture of the mix.

This page titled [7.16: Headphone Monitoring in Studios](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

7.17: Conclusion

Conclusion

Speakers and headphones are the final, vital link in the audio chain. From the physics of transduction to the artistry of placement and design, every factor contributes to how we perceive sound. Whether in the precision of studio monitors, the power of live PA systems, or the intimacy of headphones, these listening devices shape our musical and auditory experiences.

This page titled [7.17: Conclusion](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

CHAPTER OVERVIEW

8: Audio Signal Processing and Processors

- [8.1: Introduction](#)
- [8.2: Function of a Signal Processor](#)
- [8.3: Spectrum Processors](#)
- [8.4: Time Domain Processors](#)
- [8.5: Amplitude Processors](#)
- [8.6: Noise Processors](#)
- [8.7: External vs. Internal Signal Processors](#)
- [8.8: Digital vs. Analog Signal Processing](#)
- [8.9: Conclusion](#)

This page titled [8: Audio Signal Processing and Processors](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

8.1: Introduction

Introduction

Audio signal processing lies at the heart of all modern sound production. It is the method by which engineers, producers, and sound designers **shape, control, and enhance** the character of audio — transforming raw sound into a polished, expressive experience. Every recording, broadcast, film soundtrack, or live performance relies on some form of signal processing to manage tone, loudness, clarity, and spatial dimension. From the warmth of classic analog circuitry to the precision of digital plugins, processors allow us to manipulate the fundamental elements of sound — **frequency, amplitude, time, and noise**. Understanding how these processors work, how they interact within the signal chain, and how to use them creatively is essential to the craft of audio engineering. This chapter explores the **function and types of signal processors**, their roles in both **analog and digital domains**, and how they are applied throughout the recording, mixing, and mastering process to achieve professional-quality sound.

This page titled [8.1: Introduction](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

8.2: Function of a Signal Processor

Function of a Signal Processor

A signal processor is an electronic or digital device designed to modify or enhance an audio signal in a controlled way. The purpose of signal processing is to improve sound quality, correct problems, or create special effects. In simple terms, processors alter one or more aspects of a signal — such as frequency, amplitude, or time — to achieve a desired result.

Signal processing can serve various purposes:

- **Correction:** Equalization to balance tonal quality, compression to control dynamic range, or noise reduction to clean up recordings.
- **Enhancement:** Adding reverb, delay, or chorus to enrich sound.
- **Creative Manipulation:** Using effects such as pitch shifting, flanging, or modulation to produce new textures.

Modern systems can process signals in real time (as sound is played or recorded) or offline (after recording, through editing or mixing software).

This page titled [8.2: Function of a Signal Processor](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

8.3: Spectrum Processors

Spectrum Processors

Spectrum processors modify the frequency content of an audio signal. These devices or software tools allow control over tonal balance, clarity, and overall color of sound. They are used to enhance the sonic quality of instruments, remove unwanted frequencies, and shape a mix so that all elements fit together properly.

There are two main methods of equalization (EQ) processing:

1. **Boost and Cut** – increasing (boosting) or decreasing (cutting) specific frequencies to emphasize or reduce certain tonal characteristics.
2. **Shelving** – adjusting all frequencies above or below a chosen point, creating smooth tonal shaping across the spectrum.

These methods are used individually or together in equalizers to sculpt the overall tonal balance of audio in both live and studio environments.

Equalizers (EQ)

An equalizer (EQ) is the most common type of spectrum processor. It allows adjustment of specific frequency bands to shape the tonal balance of audio.

Types of EQ:

- Parametric EQ
A parametric equalizer provides precise control over each frequency band. Each band typically offers three adjustable parameters:
 - Frequency: The center point of the band being adjusted.
 - Gain: The amount of boost or cut applied to that frequency.
 - Bandwidth (Q): Controls how wide or narrow the range of frequencies affected will be.
- Parametric EQs are commonly used in studios because they allow fine-tuned control over problematic or critical frequency areas.
- Graphic EQ
A graphic equalizer divides the frequency spectrum into fixed bands (for example, 31 bands in a 1/3-octave EQ). Each band is controlled by a slider that boosts or cuts that frequency range. The physical or visual layout of the sliders represents the “shape” of the frequency curve — hence the name *graphic*.

Graphic EQs are often used in live sound reinforcement for adjusting overall system tone or reducing feedback frequencies.

- Shelving EQ
A shelving equalizer boosts or cuts all frequencies above or below a selected point.
 - High-shelf EQs affect the treble region.
 - Low-shelf EQs affect the bass region.
- Peaking EQ
A peaking filter boosts or cuts a specific band around a central frequency, leaving other frequencies largely unaffected. This is the most typical filter used in parametric equalizers.

Filters

Filters are specialized EQ circuits designed to remove or isolate certain frequency ranges.

Examples include:

- High-pass filters (HPF): Remove low frequencies below a cutoff point.

- Low-pass filters (LPF): Remove high frequencies above a cutoff point.
- Band-pass filters: Allow only a specific range of frequencies through.
- Notch filters: Remove a very narrow band, often used to eliminate hum or resonance.

Filters are used in many audio applications, including crossovers, noise control, and instrument tone shaping.

Psychoacoustic Processors

A psychoacoustic processor is a type of spectrum processor that enhances perceived clarity, brightness, or presence by manipulating harmonics and phase relationships, rather than simply boosting frequencies. These devices rely on the way the human ear perceives sound rather than on actual amplitude changes.

Examples include:

- Aphex Aural Exciter: Adds synthesized harmonics to enhance detail and brightness, often used on vocals and acoustic instruments.
- BBE Sonic Maximizer: Alters phase and amplitude relationships to improve clarity and definition.
- Enhancers/Exciters: Add subtle distortion or harmonic content that makes sound appear more lively and open.

These processors are commonly used in mastering, broadcasting, and live performance to add “sparkle” and definition to a mix. Spectrum processors provide engineers with precise control over the tonal characteristics of sound. Processors like equalizers, filters, and psychoacoustic enhancers shape the frequency spectrum to achieve clarity, balance, and artistic expression.

This page titled [8.3: Spectrum Processors](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

8.4: Time Domain Processors

Time Domain Processors

Time domain processors alter the timing or phase characteristics of an audio signal. These effects are used to create a sense of space, movement, or depth in sound.

Reverberation (Reverb)

Reverb is defined as the result of many indistinguishable reflections of sound within an environment. These reflections arrive at the listener's ear at slightly different times and levels, creating a sense of acoustic space. A major component of reverb is **delay**.

Reverb has two distinct parts:

1. **Early reflections** – the first group of reflections that reach the listener shortly after the direct sound, providing spatial cues about room size and surface material.
2. **Late reflections** (reverberant tail) – the dense, lingering decay that follows, giving the impression of the space's volume and reverberation time.

Reverb informs the listener about what size space they are in — whether a small room, concert hall, or cathedral. It is one of the most common and essential effects in audio production, recreated electronically with devices or digitally using plugins.

Reverb is used to:

- Restore natural sound: Replace the room ambiance lost during close-miking or direct recording.
- Enhance fullness: Add depth and richness to vocals and instruments.
- Create special effects: Simulate large or unreal spaces, or produce unique atmospheres.

Measuring Reverb and Impulse Response

Reverb is often measured using an Impulse Response (IR) — a recording or analysis of how a space reacts to a short, transient sound such as a clap or sine wave burst.

The impulse response contains all the early and late reflections that define the acoustic character of that space. Engineers can use these measurements to reproduce or simulate real spaces in software.

A key measurement is RT60, the time it takes for reverberation to decay by 60 decibels. RT60 helps determine how “live” or “dead” a room sounds.

Types of Reverb

- Acoustic Chambers (Rooms): Real physical rooms or echo chambers built with reflective surfaces. Classic recording studios like Capitol Records used dedicated echo chambers for natural reverberation.
- Plate Reverb: Uses a suspended metal plate to create reverb vibrations. Example: *EMT 140 Plate Reverb*, famous for its warm, smooth decay.
- Spring Reverb: Uses coiled springs to create reflections, often found in guitar amplifiers. Example: *AKG BX10 Spring Reverb*.
- Digital Reverb: Simulates reverb using algorithms. Example: *Lexicon 480L*, a classic studio digital reverb known for lush, spacious sound.
- Convolution Reverb: Uses sampled impulse responses from real acoustic spaces or hardware units. By applying the IR to an audio signal, convolution reverb reproduces the exact acoustics of the sampled environment — from a concert hall to a cathedral to a vintage reverb plate.

Delay

Delay is an effect that stores the input signal and plays it back after a set time period. The delay time determines how far apart the repeats occur, while feedback controls how many repetitions are heard as the delayed signal is fed back into itself. Delay is a major component used to create reverberation effects.

Delay can produce a wide range of effects:

- **Doubling:** A very short delay (15–35 ms) that thickens the sound, often used on vocals and guitars.
- **Chorus:** Combines short delay and slight pitch modulation to simulate multiple voices or instruments.
- **Pre-Delay:** A short delay added before reverb onset to increase clarity and separation.
- **Flanging:** Extremely short delay (less than 10 ms) with modulation, producing a sweeping comb-filter sound.
- **Phasing:** Similar to flanging, but achieved by shifting the phase of the signal rather than delaying it — both create swirling movement, though phasing sounds subtler and more resonant.

Examples of classic time-based processors include:

- *Roland RE-301 Space Echo* – Tape delay and reverb unit known for warm analog echoes.
- *EMT 140* – Classic plate reverb used in countless recordings.
- *AKG BX10* – Renowned spring reverb with characteristic metallic tone.
- *Lexicon 480L* – Legendary digital delay and reverb system with lush ambient sound.

Time domain processors are essential in both live sound and studio production. They not only reproduce the natural acoustics of real spaces but also allow engineers to design entirely new ones — adding dimension, atmosphere, and creative texture to any mix.

This page titled [8.4: Time Domain Processors](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

8.5: Amplitude Processors

Amplitude (Dynamics) Processors

Amplitude processors — also known as dynamics processors — affect the dynamic range of an audio signal. The dynamic range is the difference between the loudest and softest parts of the sound. By controlling these variations, amplitude processors make audio more consistent, polished, and easier to manage in recording, mixing, or broadcasting.

Amplitude processors modify the level or dynamic response of signals. They are crucial in maintaining consistent loudness, preventing distortion, and shaping the expressive contour of performances.

Key Types Include:

- **Limiter**

A limiter prevents a signal from exceeding a set level. It acts as a fast, high-ratio compressor to protect speakers, amplifiers, or transmission systems from overload or distortion.

- **Expander**

An expander increases the dynamic range by making quiet sounds quieter and loud sounds louder, often used to restore dynamics after heavy compression.

- **Noise Gate (sometimes considered a noise processor)**

A gate mutes or reduces signals that fall below a certain threshold, effectively removing unwanted background noise or hum when no useful sound is present.

- **De-Esser (sometimes considered a noise processor)**

A de-esser targets and reduces harsh sibilant sounds (such as “S” and “T”) in speech or vocals. It acts like a frequency-selective compressor, reducing only the offending high-frequency range rather than the entire signal.

- **Compressor**

A compressor is an amplifier that reduces the dynamic range of an audio signal. It works by automatically lowering the level of loud sounds and/or raising soft sounds. In essence, it *squeezes* the difference between the loudest and softest parts of a signal.

Compressors are used to:

- Control excessive peaks in audio.
- Smooth out variations in vocal or instrumental performances.
- Maintain consistent volume levels.
- Enhance sustain and presence in instruments.
- Improve speech intelligibility.
- Provide stable output for broadcasting and live sound applications.
- Compressors are excellent tools for speech, voiceover, and broadcast work, helping to maintain a smooth, professional sound and fixing erratic audio levels.

Compressor Parameters

To control how and when compression occurs, several parameters define a compressor’s behavior:

- **Threshold:**

The level (measured in dB) above which compression begins. Signals below the threshold pass unaffected; those exceeding it are reduced.

Example: If the threshold is set at –10 dB, only sounds louder than –10 dB will be compressed.

- **Ratio:**

Determines the amount of compression applied once the signal crosses the threshold. A 3:1 ratio means that for every 3 dB the

input rises above the threshold, the output increases by only 1 dB. Higher ratios produce stronger compression (e.g., 10:1 acts nearly as a limiter). Lower ratios (2:1 or 3:1) offer gentle, musical control.

Effect: Reduces peaks and evens out performance dynamics without sounding unnatural.

- **Attack Time:**

The speed at which the compressor reacts once the signal exceeds the threshold. Fast attack (1–10 ms) catches sharp transients like drum hits; slow attack (20–100 ms) lets initial transients pass, preserving punch and articulation.

- **Release Time:**

The speed at which the compressor stops reducing gain after the signal falls below the threshold. Short release times restore dynamics quickly but may cause “pumping.” Pumping is the audible effect of pulsating as the compressor is turning on and turning off. Longer releases sound smoother and more natural.

- **Make-Up Gain:**

Compression often lowers overall signal level. Make-up gain restores lost loudness, allowing the compressed audio to match or exceed its original volume while maintaining dynamic control.

- **Knee (Hard vs Soft):**

The knee describes how abruptly compression begins at the threshold.

- Hard Knee: Compression starts immediately once the signal crosses the threshold — more aggressive and precise.
- Soft Knee: Compression is introduced gradually as the signal approaches the threshold — smoother and more musical, common in vocals and mix-bus compression.

Multiband Compression

A multiband compressor divides the audio spectrum into several frequency bands (for example: low, mid, and high) and applies separate compression to each band.

This allows independent dynamic control over different frequency ranges.

Uses:

- Tames harsh vocals without affecting bass.
- Controls booming low frequencies while preserving brightness.
- Enhances clarity and balance across the full mix.

In mastering, multiband compression is invaluable for achieving loudness and tonal consistency without over-compressing the entire signal.

Amplitude or dynamics processors are fundamental in shaping the energy and consistency of audio. They bring control to unpredictable performances, ensure clarity in spoken word or music, and are indispensable in every aspect of audio production — from live reinforcement to studio mastering.

This page titled [8.5: Amplitude Processors](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

8.6: Noise Processors

Noise Processors

Noise processors are designed to reduce, remove, or mask unwanted noise in an audio signal while preserving the clarity and integrity of the desired sound. Noise can originate from many sources — electrical hum, tape hiss, microphone preamp noise, mechanical vibrations, or background ambience.

Noise control plays a vital role in recording, live reinforcement, and broadcasting. Without it, subtle details in a mix can be masked, overall dynamic range may be reduced, and listener fatigue can increase.

Types of Noise

Noise can generally be classified into two categories:

- **Broadband Noise:** Affects a wide range of frequencies, such as tape hiss, fan noise, or wind.
- **Narrowband Noise:** Affects a specific frequency or small range, such as electrical hum (60 Hz) or fluorescent light buzz.

Each type of noise requires a different processing approach. Broadband noise often calls for spectral analysis or intelligent noise reduction, while narrowband problems are treated with filters or notch EQ.

Common Noise Processing Tools

1. Noise Gates:

A gate works by muting or reducing the volume of a signal that falls below a set threshold. When the input level exceeds that threshold (for example, a vocal line or snare hit), the gate opens and allows the sound to pass.

- Attack time determines how quickly the gate opens.
- Release time controls how long it stays open after the sound falls below threshold.

Noise gates are extremely effective for:

- Isolating drum hits from bleed.
- Eliminating background noise during pauses in speech or vocals.
- Tightening the sound of electric guitars.

2. De-Noisers:

A de-noiser reduces steady-state or continuous noise, such as tape hiss, fan hum, or air conditioning noise.

- Operates using either spectral subtraction or adaptive filtering.
- Modern de-noisers can identify the “noise print” (a short sample of only the noise) and subtract it intelligently from the audio.
- Common in restoration work, film post-production, and archival remastering.

3. De-Clickers and De-Crackers:

Used to remove transient noises such as vinyl pops, digital clicks, and crackles caused by bad edits or data errors.

- Detects short spikes or discontinuities in the waveform.
- Replaces the unwanted transient with interpolated samples for a seamless repair.

Spectral Noise Reduction

Modern digital tools have introduced spectral noise reduction, which analyzes sound across both frequency and time domains. By visualizing audio as a spectrogram (a three-dimensional plot of frequency, amplitude, and time), specific noise regions can be isolated and removed without affecting other parts of the signal.

Key techniques include:

- **Noise Profiling:** The processor captures a short “noise print” and uses it as a reference for removal.

- Spectral Editing: Engineers manually “paint out” unwanted noise, similar to retouching an image.
- Adaptive Mode: Continuously adjusts to changing noise conditions (useful for live recordings or dialogue scenes with moving microphones).

Spectral reduction is especially effective for restoring old recordings, cleaning field recordings, or removing camera and background noise in film soundtracks.

Practical Applications

Noise processors are essential tools for:

- Recording studios: Cleaning up vocal and instrument tracks.
- Broadcasting: Maintaining clear, noise-free speech.
- Film and television: Restoring production dialogue and removing environmental noise.
- Forensic audio: Enhancing intelligibility of low-level or noisy recordings.
- Archival work: Preserving vintage analog recordings with minimal artifacts.

Noise processors work at the intersection of technology and perception — separating unwanted sounds from desirable ones without destroying the integrity of the recording. Whether through analog gating, spectral subtraction, or adaptive AI processing, the goal remains the same: a cleaner, more intelligible, and more professional-sounding result.

This page titled [8.6: Noise Processors](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

8.7: External vs. Internal Signal Processors

External vs Internal Signal Processors

Plugins (Software-Based Processors)

In modern digital audio workstations (DAWs), most spectrum processing is done using plugins. A plugin is a piece of software that integrates into a host audio application to provide signal processing or effects. Plugins emulate the function of hardware devices but operate inside the computer environment. Common plugin formats include VST (Virtual Studio Technology), AU (Audio Unit), and AAX (Avid Audio eXtension).

Plugins can perform equalization, compression, reverb, noise reduction, and many other functions. They often replicate classic analog gear and provide additional digital precision such as spectrum analyzers and recallable presets.

Signal processors can be implemented either externally or internally, depending on the type of audio system and the workflow. Both approaches perform the same basic function — altering an audio signal for enhancement, correction, or creative effect — but they differ in how they integrate with the signal path and how the engineer interacts with them.

External (Hardware) Processors

External processors are stand-alone analog or digital units connected through the physical signal path of a console, interface, or recording system. They can be outboard rack gear, such as compressors, equalizers, reverbs, or effects modules.

Common examples include:

- Analog compressors like the Universal Audio 1176 or LA-2A
- Hardware EQs like the Pultec EQP-1A
- Classic digital reverbs such as the Lexicon PCM series or TC Electronic M-One

Advantages:

- Unique analog warmth and harmonic character.
- Hands-on, tactile control with real knobs and meters.
- Reliable real-time operation (no CPU latency).
- Often preferred for live sound and mastering.

Disadvantages:

- Limited flexibility compared to digital processing.
- Fixed parameter ranges.
- Requires additional cabling, routing, and maintenance.

Internal (Software) Processors

Internal processors exist as plugins or built-in effects within Digital Audio Workstations (DAWs) such as Pro Tools, Logic, Cubase, Ableton Live, and Reaper. These are virtual recreations of hardware processors or entirely new digital designs.

Advantages:

- Cost-effective and space-saving.
- Easily recallable and automatable within a project.
- Virtually limitless in parameter range and routing flexibility.
- Can emulate analog gear with remarkable accuracy.
- Allow for visual feedback through meters, graphs, and dynamic displays.

Disadvantages:

- Depend on computer processing power and can cause latency.
- May lack the subtle analog “color” or saturation of hardware units.

Signal Routing

The placement and routing of signal processors in an audio system determines how they affect the sound. There are two primary routing methods: **insert processing** and **send/return (auxiliary) processing**.

Insert Processing - Insert processors are placed directly in the signal path, so 100% of the audio passes through the device.

Common examples:

- Compressors
- Equalizers
- Gates
- De-essers

Usage:

Insert points are ideal for dynamic or corrective processing, where the **entire** signal needs to be controlled or shaped.

For example, inserting a compressor on a vocal channel ensures every word is evenly leveled before it continues to the mix bus.

Typical signal flow:

Mic/Line Input → Preamp → Insert Send → Processor → Insert Return → Fader → Output

Send/Return (Auxiliary) Processing

Send/Return processors operate in parallel with the original signal. Only a **portion** of the signal is sent to the effect processor, and the processed result is then combined with the dry (unaffected) signal.

Common examples:

- Reverbs
- Delays
- Chorus
- Flangers

Usage:

Send/Return routing is used for time-based or spatial effects, where blending the original and processed sound adds depth or ambiance. It also allows one processor to serve multiple channels simultaneously.

For example, multiple instruments can share a single reverb unit via an auxiliary send, maintaining a cohesive “room sound.”

Typical signal flow:

Channel Send → Effects Processor → Effects Return → Mix Bus

Parallel vs In-Series Processing

The way processors are connected — either in series (one after another) or parallel (side by side) — also affects the outcome.

In-Series Processing

With In-Series routing, each processor affects the full output of the previous one.

Example chain:

Microphone → EQ → Compressor → Limiter

Used for signal correction and gain control, series chains are common for vocals, drums, and mastering chains. The order matters greatly; for instance, compressing after EQ can yield very different results than compressing before.

Parallel Processing

In parallel routing, the dry (unprocessed) and wet (processed) signals are combined.

Parallel compression (also known as *New York compression*) is a classic example:

- The dry track retains dynamics and transients.
- The compressed track adds body and density.
- When mixed together, the result sounds punchy yet natural.

Parallel setups are also common for reverb, saturation, or harmonic enhancement effects.

Hybrid Systems

Modern studios often combine external hardware and internal software in hybrid systems.

Examples include:

- Using analog preamps and compressors during recording for warmth.
- Applying digital plugins for precision EQ, noise reduction, and automation during mixing.
- Routing audio through external gear using DAW insert points via an audio interface.

Hybrid setups offer the best of both worlds — analog tone and digital control.

Latency and Synchronization

When mixing hardware and software processors, latency (signal delay) can become an issue, especially in parallel routing. Modern DAWs use automatic delay compensation to align all tracks and maintain phase coherence. For precise timing effects (like delay or reverb pre-delay), maintaining synchronization between the hardware and software environment is essential.

Practical Applications

- Recording: Hardware preamps and compressors can shape tone before the signal reaches the DAW.
- Mixing: Software plugins offer recallable processing chains for fast revisions.
- Mastering: Hybrid processing often combines analog EQs and compressors with digital limiters and spectral analyzers.
- Live Sound: Hardware outboard units are valued for their reliability and zero latency.

This page titled [8.7: External vs. Internal Signal Processors](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

8.8: Digital vs. Analog Signal Processing

Digital vs. Analog Signal Processing

Audio signal processing can occur in analog or digital domains. Although the end goal is the same — to modify or enhance sound — the two approaches differ fundamentally in how they represent and manipulate audio.

Analog Signal Processing

Analog processing operates directly on the continuous electrical waveform of the audio signal. Circuits use physical components such as resistors, capacitors, transformers, transistors, and vacuum tubes to alter amplitude, frequency, or time characteristics in real time.

Characteristics:

- The signal remains continuous from input to output.
- Changes are made using voltage or current variations.
- Imparts unique tonal coloration or “warmth” due to component tolerances and harmonic distortion.
- Typically zero latency because processing happens instantaneously in the electrical domain.

Examples:

- Vintage tube compressors (e.g., Teletronix LA-2A).
- Analog equalizers (e.g., Pultec EQP-1A).
- Outboard reverb or delay units using physical components.

Analog processing is valued for its musicality and natural saturation, often adding subtle harmonics and compression that digital systems emulate but rarely duplicate perfectly.

Digital Signal Processors (DSP)

Digital processing converts the analog audio waveform into binary data (1s and 0s) using Analog-to-Digital Conversion (A/D conversion). This digital data can then be manipulated mathematically by software algorithms or digital hardware. After processing, it is converted back to analog form through a Digital-to-Analog Converter (D/A converter) for playback or monitoring.

Analog vs. Digital: Comparison

Table showing advantages of processors.

Feature	Analog Processing	Digital Processing
Signal Type	Continuous electrical waveform	Binary numerical data
Sound Quality	Warm, natural saturation; may introduce subtle distortion	Clean, precise, repeatable
Latency	None (instantaneous)	Present (conversion + processing)
Flexibility	Fixed circuitry; limited controls	Virtually unlimited parameters and automation
Noise Floor	Higher (susceptible to hum and hiss)	Extremely low (near-zero noise floor)
Maintenance	Requires calibration and component care	Software-based; easy to update
Portability	Physical hardware	Runs on computers and mobile systems

Digital Signal Processing in Practice

Modern DSP extends beyond traditional mixing tools. It enables:

- Real-time pitch correction (Auto-Tune, Melodyne)

- Dynamic spectral balancing
- AI-driven noise suppression and mastering
- Advanced convolution modeling of analog gear
- Immersive audio formats (Dolby Atmos, Ambisonics)

Thanks to the exponential power of computers and specialized DSP chips, today's software can reproduce the sonic qualities of classic analog gear while offering precision and flexibility far beyond physical hardware.

This page titled [8.8: Digital vs. Analog Signal Processing](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

8.9: Conclusion

Conclusion

Audio processors are more than tools — they are instruments of expression. A skilled engineer uses them not only to correct and refine, but to shape emotion and atmosphere. From the gentle curve of an EQ to the lush tail of a reverb, every processor becomes part of the audio experience. Mastery of these devices transforms sound into art.

This page titled [8.9: Conclusion](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

CHAPTER OVERVIEW

9: The Mixing Process

- [9.1: Introduction](#)
- [9.2: Purpose of Mixing](#)
- [9.3: Layering vs. Balancing](#)
- [9.4: Mixing Perspective and Panning \(Music Focused\)](#)
- [9.5: Stages of the Mixing Process](#)
- [9.6: The Mastering Process](#)
- [9.7: Signal Processing in Mixing](#)
- [9.8: Dynamic Range](#)
- [9.9: Audio Imaging for TV and Film](#)
- [9.10: Surround Sound Mixing](#)
- [9.11: Conclusion](#)

This page titled [9: The Mixing Process](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

9.1: Introduction

Introduction

Mixing is the process of combining multiple recorded sound sources into a cohesive, balanced, and aesthetically pleasing final product. It is both a technical and creative art that determines how each element within a recording interacts, how space and depth are perceived, and how emotion is conveyed to the listener. In professional audio production, mixing involves the use of signal processors such as equalization (EQ), compression, reverb, delay, and automation to refine and sculpt the sonic landscape. Whether it is a pop record, a film soundtrack, or a broadcast program, the mix defines the clarity, balance, and overall impact of the production. The mixing engineer serves as both a technician and an artist, shaping the emotional intent of the performance into its final form.

This page titled [9.1: Introduction](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

9.2: Purpose of Mixing

Purpose of Mixing

The primary goal of mixing is to create a balanced and unified sound where each element contributes effectively without overpowering others. In a multitrack session, raw recordings are often uneven in level, tone, and spatial position. Mixing brings these elements together to achieve clarity, focus, and musical cohesion.

Mixing serves several key purposes:

- **Balance and Clarity:** Ensure that all audio elements can be heard distinctly within the frequency spectrum.
- **Focus and Space:** Create spatial separation using panning, EQ, and reverb so elements occupy unique areas of the stereo field.
- **Dynamics and Energy:** Control dynamic range so the audio feels lively without being fatiguing or distorted.
- **Tone Shaping:** Enhance or correct tonal balance using EQ and filtering to achieve the desired timbre.
- **Emotional Impact:** Use contrast, effects, and automation to enhance the emotional and artistic intent of the song or scene.

In essence, the purpose of mixing is to translate the artist's and producer's vision into a compelling auditory experience that connects with the listener.

This page titled [9.2: Purpose of Mixing](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

9.3: Layering vs. Balancing

Layering vs. Balancing

A successful mix is the result of both **layering** and **balancing**. These two processes work together to define the structure, clarity, and spatial character of the mix.

- **Layering** refers to the arrangement and interaction of multiple sound elements across frequency ranges and time. It is the creative aspect of deciding which sounds occupy the low, mid, and high frequency regions. For instance, bass instruments may occupy the low end (20 Hz–250 Hz), vocals and guitars the midrange (250 Hz–5 kHz), and cymbals or synths the upper range (5 kHz–20 kHz). Layering allows each sound to have a defined role in the overall texture and prevents excessive masking between instruments.
- **Balancing** involves setting relative volume levels and tonal adjustments so that no element dominates or gets buried. This is achieved through fader levels, EQ, compression, and automation. Balancing ensures that audio elements blend naturally and maintain clarity across various playback systems.

Part of balancing and layering also includes **creating perspective**—establishing where a sound appears to come from in the mix. Perspective gives the listener a sense of distance and direction, making it clear whether a sound source is in the foreground, midground, or background. This spatial awareness enhances realism and emotional impact.

Proper balancing is essential for **intelligibility**—the ability of the listener to clearly understand the message, particularly in vocals, dialog, or narration. When the mix is balanced, the primary message (such as a singer’s lyrics or a film’s dialog) remains clear and discernible, while supporting instruments or effects complement rather than compete with it.

In practice, layering defines *what* goes where, and balancing defines *how much* of it is heard. Both are interdependent; a well-layered mix makes balancing easier, while proper balance reveals the effectiveness of the layering.

This page titled [9.3: Layering vs. Balancing](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

9.4: Mixing Perspective and Panning (Music Focused)

Mixing Perspective and Panning (Music Focused)

Perspective in mixing refers to the illusion of depth, width, and placement within the stereo image. It is how the listener perceives where each sound source sits in a three-dimensional sound field.

The term **panning** comes from the word *panorama*, meaning an all-encompassing view. In audio, panning refers to distributing a signal across the left and right channels of a stereo field to create width and spatial direction. The control used for this function on a console or digital mixer is called a **Pan Pot**, short for *panoramic potentiometer*—a variable resistor that determines the amount of signal sent to each channel, thus positioning the sound anywhere from hard left to hard right.

Stereo Field

- **Left–Right (Width):** Achieved through panning. Instruments are placed anywhere between the left and right speakers to create width and separation.
- **Front–Back (Depth):** Controlled with volume, reverb, and high-frequency content. Louder, brighter sounds feel closer; quieter, darker, or more reverberant sounds feel farther away.
- **Top–Bottom (Frequency):** Perceived height comes from frequency content—low frequencies seem “below,” high frequencies “above.”

In music mixing:

- The **lead vocal**, **snare drum**, **bass**, and **kick drum** typically remain centered.
- Guitars, keyboards, and background vocals are often panned outward to create width.
- Spatial effects such as stereo reverb or delay enhance the perception of size and ambience.

Surround Mixing Perspectives in Music

In surround sound music production, there are **two common approaches** to spatial design and listener orientation:

1. Traditional Approach (Audience Perspective):

The listener is placed **in front of the ensemble**, as if seated in the audience at a live concert. The principal instruments and vocals occupy the **front speakers**, while **ambience**, **audience sounds**, and **reverb returns** fill the **rear channels**. This yields a natural, performance-style soundstage.

2. Perspective Approach (On-Stage Perspective):

The listener is positioned **on stage within the ensemble**, looking outward toward the audience. Instruments are placed around the listener according to their true stage positions—drums behind, guitars and keyboards to the sides, vocals in front. This immersive approach gives a strong sense of presence, as if the listener is part of the performance itself.

Both perspectives are valid artistic choices. The **audience perspective** is common in orchestral, jazz, and live recordings, while the **on-stage perspective** is often used in pop, rock, and immersive music to enhance energy and immediacy.

A well-panned mix—stereo or surround—offers clarity, avoids masking, and mirrors natural listening perception. Thoughtful panning builds space and realism that engage the listener on multiple dimensions.

This page titled [9.4: Mixing Perspective and Panning \(Music Focused\)](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

9.5: Stages of the Mixing Process

Stages of the Mixing Process

Mixing is not a single step but a structured process that spans across **pre-production**, **production**, and **post-production** phases.

Pre-Production

Before any mixing begins, this stage involves both creative and logistical preparation. It lays the foundation for everything that follows.

Pre-production includes the **writing of the song or script**, **finding and selecting the performers**—whether actors for a film or musicians for a recording—**rehearsing the material**, and **booking the recording studio and engineer**. All of these elements represent both time and financial investment, and can have a **significant cost** depending on the scope of the project.

Once creative and personnel arrangements are in place, technical preparation follows:

- Session organization and labeling tracks
- Checking phase alignment between microphones
- Grouping similar instruments (drum bus, vocal bus, etc.)
- Setting initial rough balances and reference levels
- Creating monitor mixes

Proper preparation ensures a smooth, efficient mixing session and minimizes costly errors or delays later in production.

Production (The Recording Stage)

The production phase is where the actual performances are captured and refined before the final mix begins. It includes:

- **Recording the song or script:** Capturing the raw performances of musicians, vocalists, or actors in the studio.
- **Overdubs and multiple takes:** Recording additional layers or re-takes to improve performances or add new parts.
- **Adding backups:** Recording background singers or harmonies to support the lead vocal.
- **Playing solos:** Recording featured instrumental or vocal solos that enhance the arrangement.
- **Alternate takes and punch-ins:** Re-recording small sections to correct mistakes or improve phrasing without replacing the entire take.
- **Programming parts:** Creating or sequencing musical elements that are not performed in real time, such as synthesized instruments, drum machines, or sound effects.

After all performances are complete, the engineer moves into the technical side of production, where artistic and sonic decisions begin to shape the mix:

- Balancing levels
- Applying EQ, compression, gating, and effects
- Establishing panning positions
- Creating automation for dynamics or movement
- Continuously referencing on different playback systems

This stage defines the **sound identity** and emotional tone of the project.

Post-Production

Post-production brings together all recorded and processed material into a cohesive final mix, ready for mastering or delivery. It involves both technical refinement and organizational control.

Key post-production tasks include:

1. **Final Mix:** The engineer creates a final stereo mix of all the tracks, ensuring that all elements are properly balanced and that the mix is ready for mastering.

- **Editing of tracks:** Cleaning up takes, trimming silences, fixing timing issues, and ensuring seamless transitions between edits.
- **Creating track groups and sub-mixes:** Organizing related instruments (such as drums, vocals, or strings) into busses or stems for easier control and processing.
- **Adding comments or notes to tracks:** Documenting mix decisions or reminders for revision, ensuring consistency across sessions or engineers.
- **Applying signal processing:** Refining tonal balance, dynamics, and spatial depth using EQ, compression, reverb, and delay.
- **Panning and balancing:** Establishing the spatial image and volume relationships between all mix elements.
- **Setting up the Master Fader:** Managing the overall output level, applying final bus compression or limiting, and preparing the stereo mix for mastering.

This final stage ensures that all elements are organized, balanced, and sonically unified, producing a professional mix that is ready for mastering and distribution.

This page titled [9.5: Stages of the Mixing Process](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

9.6: The Mastering Process

The Mastering Process

Mastering is the final stage of audio production where the mixed stereo track is optimized for playback across all systems and formats. The mastering engineer adjusts overall EQ, compression, limiting, and stereo width to ensure the track is polished and competitive in loudness and tonal balance.

The **mastering engineer** holds a **unique and specialized role**, often separate from the mixing engineer. While the mixing engineer works with individual multitrack elements, the mastering engineer only deals with the **final stereo (or surround) file**. Their goal is to enhance the finished mix without altering its artistic intent.

The mastering engineer requests an **uncompressed version** of the final mix output (usually at full bit depth and sample rate) so they can apply their own carefully chosen **compression, equalization, and limiting**. This ensures that the overall loudness, tonal character, and dynamic range are optimized for the intended playback medium.

In addition to tonal and dynamic shaping, the mastering engineer is also responsible for:

- Setting precise **fade-ins and fade-outs** for smooth beginnings and endings of tracks.
- **Sequencing (ordering)** the tracks on an album or collection to create musical flow and pacing.
- **Ensuring consistency** of tone, loudness, and balance across all tracks on an album or project.
- **Preparing and exporting the final master file**—a definitive, high-quality version ready for replication or digital distribution.

Depending on the project, the mastering engineer's output may be:

- A **master file** for duplication on CD or vinyl.
- A **high-resolution digital master** for uploading to streaming platforms.
- A **final printmaster** for **TV or film**, delivered for synchronization with picture during an **online mix**.

Key mastering tasks include:

- Equalizing for overall tonal consistency
- Controlling peaks through compression and limiting
- Adjusting dynamic range for loudness targets (streaming, broadcast, or physical media)
- Sequencing and spacing tracks for albums
- Embedding metadata (ISRC codes, track titles)
- Converting to final delivery formats (WAV, MP3, DDP for CD, etc.)

The mastering process gives the mix its final sheen and ensures it translates well across all playback environments.

This page titled [9.6: The Mastering Process](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

9.7: Signal Processing in Mixing

Signal Processing in Mixing

Signal processing refers to the use of devices or software that modify audio characteristics. These tools shape tone, control dynamics, and create spatial effects. *Revisit Chapter 8 for a more in-depth explanation of signal processors.*

Common processors include:

- **Equalization (EQ):** Adjusts frequency balance to enhance clarity or correct masking.
 - **Subtractive EQ:** Removes problematic or excessive frequencies rather than boosting others. By cutting unwanted resonances or muddiness—often in the 200–400 Hz range—or taming harshness in the 2–4 kHz region, the mix becomes cleaner and more natural while preserving headroom.
 - **Notching EQ:** Carves out narrow frequency “slots” so each instrument or vocal has its own tonal niche.
- **Compression:** Controls dynamic range by reducing the difference between loud and soft signals.
- **Reverb:** Simulates acoustic spaces, adding depth and realism. A major component of reverberation is **delay**, formed by countless overlapping reflections arriving at slightly different times.
- **Delay:** Produces discrete echoes or widening effects; can thicken vocals, simulate reflections, or add rhythmic motion.
- **Modulation Effects (chorus, flanger, phaser):** Add movement and texture by varying delay or phase.
- **Automation:** Dynamic control of levels, pan, and effects throughout the song.

Proper use of signal processing enhances musicality and listener engagement without over-processing the mix. Subtractive and notching EQ are fundamental for giving every element its own sonic identity, ensuring balance, focus, and intelligibility.

This page titled [9.7: Signal Processing in Mixing](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

9.8: Dynamic Range

Dynamic Range

Dynamic range is the difference between the quietest and loudest parts of a mix, measured in decibels (dB). A well-managed dynamic range provides impact and clarity without distortion or listener fatigue.

It is essential that **audio levels remain within the dynamic range of the medium** for which the program is intended. If the range is too wide, loud sections may **clip or distort**, while soft parts fall below the noise floor.

Table showing dynamic range in dB of various media.

Medium	Approx. Dynamic Range	Notes
Compact Disc (CD)	~96 dB (85dB min)	16-bit digital; wide, clean playback.
Cassette Tape	~50–60 dB	Limited by hiss; Dolby NR improves slightly.
Vinyl Record (LP)	~55–65 dB	Surface noise and groove limits reduce quiet passages.
DVD / Blu-ray	~110–120 dB	24-bit digital; ideal for film soundtracks.
FM Radio Broadcast	~50–60 dB	Highly compressed for consistent loudness.
Television Broadcast	~45–60 dB	Regulated by loudness standards(–24 LUFS)

Mix engineers tailor compression and limiting to suit the delivery format—radio and TV require tighter control, while film and high-resolution media can preserve wide dynamics. The goal is to stay within the medium’s technical limits while maintaining artistic expression.

This page titled [9.8: Dynamic Range](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

9.9: Audio Imaging for TV and Film

Audio Imaging for TV and Film

In film, television, and broadcast, mixes are organized around **DME (Dialog, Music, and Effects)**.

- **Dialog** conveys the story and must remain clear and natural.
- **Music** adds emotional tone and pacing.
- **Effects** (Foley, ambience, and hard effects) create realism and spatial depth.

Natural Placement and Spatial Perspective

A good starting point is to **mimic the natural on-screen position** of each sound. If a character speaks from the back-left of the frame, their voice might be placed slightly left or in the back-left speaker in surround sound mixing. While this realism helps orientation, the sound field must also **fill the entire stereo or surround frame** for balance and immersion. Artistic judgment takes precedence over strict accuracy.

Dialog Localization

Dialog should be **anchored near the center** of the stereo image (or center channel in surround). This ensures stability when cameras cut between angles so the voice doesn't audibly jump. Even as visuals shift, consistent center placement maintains a cohesive listening experience.

Balance and Loudness

- **Dialog:** Highest priority; EQ and compression enhance intelligibility.
- **Music and Effects:** Balanced around dialog to avoid masking.
- **Spatial Imaging:** Reverb and ambience match scene environments—close-ups sound dry; wide shots sound spacious.
- **Loudness Standards:** Broadcast delivery requires -24 LUFS (U.S.) or -23 LUFS (Europe).

Sound placement, tone, and level guide the audience's focus, supporting the story through a seamless blend of realism and artistry.

This page titled [9.9: Audio Imaging for TV and Film](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

9.10: Surround Sound Mixing

Surround Sound Mixing

Surround mixing expands the flat stereo plane into a three-dimensional environment, immersing the listener with sound from multiple directions. It is used in film, television, gaming, and immersive music production.

Surround Sound Formats

- **5.1 Surround:** Left, Center, Right, Left Surround, Right Surround, LFE (Low-Frequency Effects).
- **7.1 Surround:** Adds rear channels for greater envelopment.
- **Dolby Atmos / Object-Based:** Treats sounds as movable objects in 3-D space—including overhead positions—rendered dynamically for any speaker layout.

Channel Roles (Example 5.1)

Table showing channels of the 5.1 surround format

Channel	Purpose
Front Left/Right	Main stereo image for music, ambience, and effects.
Center	Anchors dialog or lead vocal for clarity.
Left/Right Surrounds	Provide environmental ambience and motion.
LFE	Low-frequency impacts (explosions, rumbles) below ~120 Hz.

Mixing Strategy and Localization

- **Dialog/Leads:** Stay in center to remain stable.
- **Ambience & Effects:** Use surround channels for depth and motion.
- **Music Bed:** Front channels carry core music; reverbs or pads may extend into surrounds.
- **Reverb/Delay:** Feed both front and rear speakers for immersive spatial realism.
Proper localization ties audio motion to visual cues without disorienting the listener.

LFE and Bass Management

The **LFE** channel is reserved for special low-frequency effects, not general bass. Most systems redirect bass via **bass management**, so engineers:

- Filter non-LFE channels to prevent buildup.
- Send only impactful moments to the LFE.
- Monitor levels to avoid overdriving subwoofers.

Downmixing and Compatibility

Surround mixes must translate correctly to stereo and maintain coherence when folded down. Folding down a mix is the process of combining a multi-channel project into a different format of channels such as going from a 7.1 mix to a stereo mix. Engineers check for:

- **Dialog clarity and phase integrity** during downmixing.
- **Balanced ambience** that doesn't overpower or cancel out.

- **Proper summing levels** that comply with broadcast or streaming loudness standards.

Immersive Audio and the Future

Object-based formats such as **Dolby Atmos**, **DTS:X**, and **Sony 360 Reality Audio** now allow mixers to place sound “objects” anywhere in three-dimensional space—including above and behind the listener. Playback systems render these dynamically, adapting automatically to headphones, home theaters, or cinema arrays.

This new generation of immersive audio enables engineers to create experiences that extend beyond traditional left-right-front-back placement, offering vertical movement, full spatial depth, and true listener envelopment.

This page titled [9.10: Surround Sound Mixing](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

9.11: Conclusion

Conclusion

Mixing is where science and art converge—where acoustical precision meets emotional storytelling. From the careful arrangement of frequencies to the panoramic sculpting of space and depth, every decision shapes how the listener experiences the performance. A great mix translates faithfully across all playback systems, communicates clearly, and immerses the audience in sound that moves, breathes, and inspires.

This page titled [9.11: Conclusion](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

CHAPTER OVERVIEW

10: Audio Over the Internet

- [10.1: Introduction](#)
- [10.2: Streaming Audio](#)
- [10.3: Subscription-Based Listening](#)
- [10.4: Audio File Formats](#)
- [10.5: Audio File Size and Bitrate Considerations](#)
- [10.6: Audio Quality vs. File Size](#)
- [10.7: Podcasting](#)
- [10.8: What Happened to Terrestrial Radio?](#)
- [10.9: Alternatives to Streaming](#)
- [10.10: The Future of Audio](#)
- [10.11: Conclusion](#)

This page titled [10: Audio Over the Internet](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

10.1: Introduction

Introduction

The way people listen to audio has dramatically evolved over the past few decades. Once dominated by vinyl records, cassette tapes, and CDs, audio distribution has shifted to digital files, downloadable music, and now streaming over the internet. The modern listener may never own a physical album or even a digital file — they simply subscribe to a service and press play. Understanding how audio travels over the internet, the formats used, the trade-offs between quality and file size, and the cultural implications of streaming is essential to understanding the future of sound.

This chapter explores file formats, streaming technology, podcasting, subscription platforms, what has happened to traditional radio, and where audio consumption is heading next. Since this chapter is very technical, it is being presented in an easy to read bulleted format. This format will allow for future technologies to be added as needed.

This page titled [10.1: Introduction](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

10.2: Streaming Audio

Streaming Audio

Streaming is the continuous transmission of audio over a network without requiring the user to fully download the file before listening.

How Streaming Works

1. A server stores audio files.
2. When a listener presses play, compressed chunks of the audio are sent over the internet.
3. The user's device buffers several seconds of audio ahead of playback.
4. Playback begins while data continues to stream in real-time.

Advantages of Streaming

- No need to store large files.
- Immediate playback.
- Access to large libraries of content.

Disadvantages

- Requires a stable internet connection.
- Sound quality varies depending on compression.
- Rights can be revoked; you don't **own** the music.

Streaming can be **on-demand** (Spotify, Apple Music) or **live** (internet radio stations, Twitch, live podcast recordings).

This page titled [10.2: Streaming Audio](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

10.3: Subscription-Based Listening

Subscription-Based Listening

Subscription platforms changed listening from *ownership* to *access*.

Examples

- Spotify
- Apple Music
- Tidal
- Amazon Music
- YouTube Music

Business Model

Users pay a monthly fee to access a vast library. Artists are paid **per stream**, not per sale, leading to ongoing debate regarding fairness and revenue transparency.

Listening Behavior Shift

Table showing evolution of streaming culture.

Before Streaming	After Streaming
Buy an album for \$10–\$20	Pay monthly for access to millions of songs
Limited library	Nearly unlimited library
Commitment to artists	Shortened attention spans and skipping behavior
Physical and digital ownership	No ownership — only licensed access

This page titled [10.3: Subscription-Based Listening](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

10.4: Audio File Formats

Audio File Formats

Different formats balance quality and file size in different ways.

Lossy Formats

Uses compression schemes that permanently removes audio data to reduce size.

Table showing file types.

Format	Notes	Typical Use
MP3	Most common; older standard	Music downloads, streaming
AAC	More efficient than MP3 at same bitrate	Apple Music, YouTube, Amazon
OGG Vorbis	Open-source; high efficiency	Spotify streams (free)

Lossless Formats

Preserves **all** original audio data.

Table showing 4 audio file types.

Format	Notes	Typical Use
FLAC	Free lossless compression	Spotify (premium), Audiophile streaming, archiving
ALAC	Apple's version of FLAC	Apple Music Lossless
WAV AIF	Uncompressed PCM audio Audio Interchange File	Recording, editing, professional production Created by Apple for iOS

This page titled [10.4: Audio File Formats](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

10.5: Audio File Size and Bitrate Considerations

Audio File Size and Bitrate Considerations

File size is influenced by:

- Sample rate (e.g., 44.1 kHz, 48 kHz, 96 kHz)
- Bit depth (e.g., 16-bit, 24-bit)
- **Bitrate** (kilobits per second, kbps)

Typical Bitrates

Table showing bitrates and example file types.

Quality Level	Bitrate	Example
Low Quality	96 kbps	Mobile data saving mode
Standard Streaming	128–256 kbps	Spotify free tier, Apple default
High Quality Streaming	320 kbps	Spotify Premium
Lossless	700–1500+ kbps	FLAC / ALAC
Studio Quality	2000–4000+ kbps	24-bit / 96 kHz files

Higher bitrate = higher fidelity but requires **more bandwidth and storage**.

This page titled [10.5: Audio File Size and Bitrate Considerations](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

10.6: Audio Quality vs. File Size

Audio Quality vs. File Size

- **Lossy compression** removes frequencies perceived as less important to human hearing.
- At lower bitrates, this becomes noticeable:
 - Reduced stereo width
 - Smearing of transients
 - Loss of high-frequency detail (“swishy” or “watery” sound quality)

Lossless audio is preferred for:

- Critical listening
- Professional editing
- Archival preservation

Lossy audio is acceptable for:

- Casual listening
- Mobile streaming
- Limited bandwidth situations

This page titled [10.6: Audio Quality vs. File Size](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

10.7: Podcasting

Podcasting

Podcasting revitalized spoken-word audio.

Why Podcasts Became Popular

- Easy to produce and distribute.
- Serve niche audiences.
- Portable — listeners consume during commutes, workouts, and daily tasks.

Typical Podcast Workflow

1. Record voice tracks (often in WAV).
2. Edit + mix.
3. **Export in compressed format** (often MP3 or AAC).
4. Upload to a hosting service that distributes to platforms:
 - Apple Podcasts
 - Spotify
 - Google Podcasts
 - RSS-based directories

Podcasting democratized broadcasting — **anyone can host a show now.**

This page titled [10.7: Podcasting](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

10.8: What Happened to Terrestrial Radio?

What Happened to Terrestrial Radio?

Terrestrial radio is traditional radio which broadcasts their signal over the airwaves. It is not gone, but its cultural role has shifted.

Factors in Decline

- Streaming allows **on-demand choice**.
- Listeners prefer **no commercials**.
- Younger generations rarely use AM/FM receivers.
- Car systems now include Bluetooth and streaming apps.

Still Relevant Because:

- Radio reaches large audiences in cars and workplaces.
- Local sports, news, and emergency broadcasts still rely on radio.
- Some listeners enjoy curated DJ programming.

But the **center of influence** has moved from radio to streaming playlists and algorithmic recommendations.

This page titled [10.8: What Happened to Terrestrial Radio?](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

10.9: Alternatives to Streaming

Alternatives to Streaming

Some listeners resist streaming for cost, ownership, or aesthetic reasons.

Alternatives

- **Vinyl Records** (tactile, analog warmth, collectible)
- **CDs** (lossless digital, reliable archives)
- **Digital Downloads** (ownership without physical storage)
- **Lossless FLAC Libraries** (stored on hard drives or NAS systems)
- **Hi-Fi Local Playback Systems** (streamers / DACs that play local files)

There is a growing **audiophile renaissance** valuing ownership and high fidelity.

This page titled [10.9: Alternatives to Streaming](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

10.10: The Future of Audio

The Future of Audio

Several trends shape where listening is going:

1. Higher Quality Streaming

Lossless and even high-resolution streaming are becoming standard.

2. Personalized and Adaptive Audio

Algorithms tailor music to individual tastes and mood.

3. Spatial Audio / Immersive Formats

- Dolby Atmos Music
- Binaural rendering for headphones

This expands audio beyond the stereo soundstage.

4. AI-Generated Music

Music customized in real time for:

- Focus
- Relaxation
- Workout pacing
- Video soundtracks

5. Continued Revival of Ownership Formats

Vinyl, cassette, and boutique physical releases retain cultural value.

This page titled [10.10: The Future of Audio](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

10.11: Conclusion

Conclusion

Audio over the internet has reshaped how we access, experience, and value sound. Streaming services dominate everyday listening, offering vast libraries with minimal storage needs, but introduce trade-offs in ownership, quality, and artist compensation. Podcasts democratized broadcasting, while terrestrial radio has shifted into a supporting cultural role. The future of audio lies in personalization, immersive sound formats, and a renewed appreciation for audio quality and intentional listening.

This page titled [10.11: Conclusion](#) is shared under a [CC BY-SA 4.0](#) license and was authored, remixed, and/or curated by [Geoffrey Dunbar](#).

Index

D

dire

Glossary

Glossary of audio terms

Term	Definition
AAC	Advanced Audio Coding. A lossy digital audio compression format used by streaming platforms such as Apple Music and YouTube.
Acoustical Phase	The position of a waveform relative to a reference point in time within its oscillation cycle.
Acoustic Energy	Energy carried by sound waves through a medium such as air or water.
Active Mixer	A mixer that includes powered electronic circuits capable of amplifying and shaping signals.
ADAT	Alesis Digital Audio Tape. A digital optical connection capable of transferring multiple channels of digital audio between devices.
AES/EBU	Audio Engineering Society/European Broadcasting Union. A professional digital audio interface standard commonly transmitted through XLR connectors.
AIFF	Audio Interchange File Format. An uncompressed digital audio file format commonly used in professional recording environments.
Algorithmic Reverb	Digital reverberation generated using algorithms rather than recordings of real spaces.
Analog Audio	A continuous electrical representation of a sound wave.
Analog-to-Digital Conversion (A/D)	The process of converting analog sound signals into digital data.
Amplitude	The strength of a sound wave, which corresponds to perceived loudness.
Attack Time	The speed at which a compressor begins reducing gain after a signal exceeds the threshold.

Term	Definition
Auditory Nerve	The nerve that carries electrical signals from the cochlea to the brain.
Auxiliary Bus	A routing path used to send signals to effects processors or monitor mixes.
Bass	The lowest region of the audible frequency spectrum.
Binary Code	A system of representing digital data using combinations of 0s and 1s.
Bit Depth	The number of bits used to represent each digital audio sample.
Bitrate	The amount of audio data transmitted per second, typically measured in kilobits per second.
Blu-Ray Disc	A high-capacity optical disc capable of storing large amounts of digital audio and video data.
Bus (Audio Bus)	A signal path that combines multiple audio signals into a single output.
Cardioid	A microphone pickup pattern that captures sound mainly from the front while rejecting rear sound.
Channel Strip	A section of a mixer or console containing controls for a single audio input.
Chromatic Scale	A musical scale consisting of twelve equally spaced pitches within an octave.
Clipping	Distortion that occurs when an audio signal exceeds the maximum level a system can handle.
Cochlea	A spiral-shaped structure in the inner ear that converts vibrations into electrical signals.
Compressor	A dynamics processor that reduces the dynamic range of an audio signal.
Condenser Microphone	A microphone that uses a

Term	Definition
	capacitor element and requires external power such as phantom power.
Constructive Interference	When sound waves combine in phase, increasing amplitude.
Convolution Reverb	A digital reverb that recreates real acoustic spaces using impulse responses.
Decibel (dB)	A logarithmic unit used to measure sound intensity or signal level.
Delay	An audio effect that repeats a signal after a specified period of time.
De-Esser	A processor designed to reduce harsh “S” and “T” sounds in speech recordings.
Destructive Interference	Cancellation of sound waves when they are out of phase.
Digital Audio	Audio represented as numerical samples rather than continuous electrical signals.
Digital Audio Workstation (DAW)	Software used to record, edit, process, and mix digital audio.
Digital-to-Analog Conversion (D/A)	The process of converting digital audio data into an analog signal for playback.
Digital Signal Processing	Manipulation of audio signals using digital algorithms.
Direct Sound	Sound that travels directly from the source to the listener without reflections.
Dynamic Microphone	A microphone that generates signal through electromagnetic induction using a moving coil.
Dynamic Range	The difference between the quietest and loudest sounds a system can reproduce.
Early Reflections	The first reflections of sound arriving shortly after the direct sound in an acoustic space.
Equal Loudness Contours	Graphs showing how human hearing perceives different frequencies at varying loudness levels.
Equalization (EQ)	Adjusting frequency balance

Term	Definition
	within an audio signal.
Expander	A processor that increases dynamic range by reducing the level of quiet signals.
Field Recorder	A portable recording device used for capturing audio outside the studio.
Filter	An electronic circuit used to remove or isolate certain frequency ranges.
Flanging	An audio effect created by combining a signal with a slightly delayed copy of itself.
Foley	The recreation of everyday sound effects for film and video production.
Frequency	The number of cycles of a sound wave per second, measured in Hertz.
Frequency Response	The range of frequencies a device can reproduce and how evenly it reproduces them.
Gain	Amplification applied to an audio signal.
Graphic Equalizer	An equalizer with fixed frequency bands controlled by sliders.
Harmonics	Frequencies that occur at integer multiples of a fundamental frequency.
Headphones	Personal monitoring devices used to listen to audio signals directly.
Hertz (Hz)	The unit used to measure frequency cycles per second.
High-Pass Filter	A filter that removes frequencies below a selected cutoff point.
Hypercardioid	A microphone pickup pattern with narrow front sensitivity and slight rear pickup.
Impedance	Electrical resistance to alternating current in an audio circuit.
Impulse Response	A measurement of how a space responds to a short sound burst.

Term	Definition
Infrasound	Frequencies below the human hearing range (below 20 Hz).
Interaural Level Difference (ILD)	The difference in sound intensity between the two ears used for localization.
Interaural Time Difference (ITD)	The difference in arrival time of a sound at each ear.
Limiter	A processor that prevents signals from exceeding a specific level.
Line Level	Standard signal level used for connections between audio equipment.
Loudness Meter	A meter designed to measure perceived loudness of audio signals.
Low-Pass Filter	A filter that removes frequencies above a selected cutoff point.
MADI	Multichannel Audio Digital Interface. A professional audio communication protocol (also known as AES10) designed to transmit up to 64 channels of digital audio over a single coaxial (BNC) or fiber-optic cable.
Master Bus	The final summing path that combines all channels of a mix.
Mastering	The final stage of audio production where mixes are optimized for distribution.
Metering	Visual monitoring of signal levels within audio equipment.
Microphone	A transducer that converts sound waves into electrical signals.
MIDI	Musical Instrument Digital Interface. A communication protocol for electronic instruments and software.
Mixing	The process of combining multiple audio tracks into a balanced final recording.
Multiband Compressor	A compressor that applies separate compression to

Term	Definition
	different frequency ranges.
Multitrack Recording	Recording multiple sound sources on separate tracks for later mixing.
Noise Gate	A processor that reduces or mutes signals below a specified level.
Nyquist-Shannon Theorem	A principle stating that sampling rate must be at least twice the highest frequency to reproduce audio accurately.
Omnidirectional	A microphone pattern that captures sound equally from all directions.
Oscillator	A device that generates test tones used for calibration.
Overtones	Frequencies above the fundamental that contribute to a sound's timbre.
Panning	Placing a sound within the stereo field between left and right channels.
Parametric Equalizer	An EQ allowing adjustment of frequency, gain, and bandwidth.
Passive Mixer	A mixer that combines signals without providing amplification.
Phantom Power	A 48-volt DC supply used to power condenser microphones through XLR cables.
Phase	The relative timing relationship between waveforms.
Pitch	The perceived highness or lowness of a sound determined by frequency.
Plugin	Software used within a DAW to process audio signals.
Polar Pattern	The directional sensitivity of a microphone.
Post-Production	The stage after recording where editing, mixing, and sound design occur.
Preamp	A device that amplifies weak microphone signals to line level.

Term	Definition
Pre-Delay	A short delay added before reverb begins.
Psychoacoustics	The study of how humans perceive sound.
Quantization	Converting continuous analog signals into discrete digital values.
Rarefaction	The low-pressure portion of a sound wave where particles spread apart.
Ratio	The amount of compression applied once a signal exceeds the threshold.
Release Time	The time required for a compressor to stop reducing gain.
Reverb	Reflected sound that creates a sense of space and ambience.
Ribbon Microphone	A microphone that uses a thin metal ribbon suspended in a magnetic field.
RT60	Reverberation Time 60dB. The time it takes for reverberation to decay by 60 decibels.
Sample Rate	The number of samples captured per second in digital recording.
Sampling	The measurement of an analog signal at discrete time intervals to create digital audio.
Signal-to-Noise Ratio	The relationship between desired audio signal level and background noise.
Sine Wave	A pure tone containing a single frequency.
Sound Pressure Level (SPL)	A measurement of sound intensity expressed in decibels.
Spectrum	The full range of frequencies contained in sound.
Stereo Field	The spatial placement of sound between left and right speakers.
Streaming Audio	Continuous playback of audio transmitted over a network.
Submix	A group of channels controlled together within a mix.

Term	Definition
Threshold	The level at which compression begins.
Timbre	The tonal quality that distinguishes different sound sources.
Transducer	A device that converts one form of energy into another.
Ultrasound	Frequencies above the human hearing range (above 20 kHz).
VU Meter	Volume Unit. A meter that measures average signal level.
Wavelength	The physical distance between repeating points of a sound wave.
Word Clock	A synchronization signal that keeps digital audio devices operating in time with one another.
XLR Connector	eXternal Line Return. A professional three-pin connector commonly used for microphones and balanced audio signals. Originally, it referred to the evolution of Cannon Electric's "X" series connectors: X (series), L (Latch), and R (Resilient rubber).

Detailed Licensing

Overview

Title: Understanding Sound From Ear to Engineer

Webpages: 150

All licenses found:

- [CC BY-SA 4.0](#): 98.7% (148 pages)
- [Undeclared](#): 1.3% (2 pages)

By Page

- Understanding Sound From Ear to Engineer - [CC BY-SA 4.0](#)
 - Front Matter - [CC BY-SA 4.0](#)
 - [TitlePage](#) - [CC BY-SA 4.0](#)
 - [InfoPage](#) - [CC BY-SA 4.0](#)
 - [Table of Contents](#) - [Undeclared](#)
 - [Licensing](#) - [CC BY-SA 4.0](#)
 - 1: The Characteristics of Sound - [CC BY-SA 4.0](#)
 - 1.1: Introduction - [CC BY-SA 4.0](#)
 - 1.2: The Sound Wave - [CC BY-SA 4.0](#)
 - 1.3: Frequency - [CC BY-SA 4.0](#)
 - 1.4: Amplitude - [CC BY-SA 4.0](#)
 - 1.5: Velocity - [CC BY-SA 4.0](#)
 - 1.6: Wavelength - [CC BY-SA 4.0](#)
 - 1.7: Acoustical Phase - [CC BY-SA 4.0](#)
 - 1.8: Sound Envelope - [CC BY-SA 4.0](#)
 - 1.9: Direct, Early, and Reverberant Sound - [CC BY-SA 4.0](#)
 - 2: The Auditory System - [CC BY-SA 4.0](#)
 - 1.10: Conclusion - [CC BY-SA 4.0](#)
 - 2.1: Introduction - [CC BY-SA 4.0](#)
 - 2.2: The Ear - [CC BY-SA 4.0](#)
 - 2.3: How Hearing Works - [CC BY-SA 4.0](#)
 - 2.4: Hearing Loss - [CC BY-SA 4.0](#)
 - 2.5: Symptoms of Hearing Loss - [CC BY-SA 4.0](#)
 - 2.6: Hearing Protection - [CC BY-SA 4.0](#)
 - 2.7: Hearing Aids and Cochlear Implants - [CC BY-SA 4.0](#)
 - 2.8: Fun Fact. How Loud Is Too Loud? - [CC BY-SA 4.0](#)
 - 2.9: Sound Pressure Level (SPL) - [CC BY-SA 4.0](#)
 - 2.10: Tinnitus- The Ringing in the Ears - [CC BY-SA 4.0](#)
 - 2.11: Conclusion - [CC BY-SA 4.0](#)
 - 3: Psychoacoustics - [CC BY-SA 4.0](#)
 - 3.1: Introduction - [CC BY-SA 4.0](#)
 - 3.2: Properties of Sound - [CC BY-SA 4.0](#)
 - 3.3: Frequency Spectrum - [CC BY-SA 4.0](#)
 - 3.4: Octave Groupings - [CC BY-SA 4.0](#)
 - 3.5: Instrument Ranges - [CC BY-SA 4.0](#)
 - 3.6: Equal Loudness Principle - [CC BY-SA 4.0](#)
 - 3.7: Quality of Sound (Timbre) - [CC BY-SA 4.0](#)
 - 3.8: Binaural Hearing vs. Stereo Hearing - [CC BY-SA 4.0](#)
 - 3.9: Conclusion - [CC BY-SA 4.0](#)
 - 4: Audio Mixers, Consoles, and DAW Control Surfaces - [CC BY-SA 4.0](#)
 - 4.1: Introduction - [CC BY-SA 4.0](#)
 - 4.2: Faders vs. Knobs - [CC BY-SA 4.0](#)
 - 4.3: Passive vs. Active - [CC BY-SA 4.0](#)
 - 4.4: Function of a Mixer/Console - [CC BY-SA 4.0](#)
 - 4.5: Balance and Combine Levels - [CC BY-SA 4.0](#)
 - 4.6: Monitoring and Metering - [CC BY-SA 4.0](#)
 - 4.7: The Mix Bus and Bussing - [CC BY-SA 4.0](#)
 - 4.8: Routing and Signal Flow - [CC BY-SA 4.0](#)
 - 4.9: Major Sections of a Mixer/Console - [CC BY-SA 4.0](#)
 - 4.10: Broadcast vs. Production Consoles - [CC BY-SA 4.0](#)
 - 4.11: Features of Most Consoles - [CC BY-SA 4.0](#)
 - 4.12: The Audio Patchbay - [CC BY-SA 4.0](#)
 - 4.13: Automation - [CC BY-SA 4.0](#)
 - 4.14: DAW Control Surfaces - [CC BY-SA 4.0](#)
 - 4.15: Conclusion - [CC BY-SA 4.0](#)
 - 5: Audio Recording - [CC BY-SA 4.0](#)
 - 5.1: Introduction - [CC BY-SA 4.0](#)
 - 5.2: Digital vs. Analog - [CC BY-SA 4.0](#)
 - 5.3: Sample Rate - [CC BY-SA 4.0](#)
 - 5.4: Nyquist-Shannon Theory - [CC BY-SA 4.0](#)
 - 5.5: Bit Depth (Resolution) - [CC BY-SA 4.0](#)
 - 5.6: Quantization - [CC BY-SA 4.0](#)
 - 5.7: Binary Code - [CC BY-SA 4.0](#)

- 5.8: Common Recording Systems - CC BY-SA 4.0
- 5.9: The Digital Audio Workstation - CC BY-SA 4.0
- 5.10: Audio Interface - CC BY-SA 4.0
- 5.11: Digital Audio Connections - CC BY-SA 4.0
- 5.12: Recording Media Types - CC BY-SA 4.0
- 5.13: MIDI and Its Use - CC BY-SA 4.0
- 5.14: Analog Audio Connectors - CC BY-SA 4.0
- 5.15: Digital Audio Networking - CC BY-SA 4.0
- 5.16: Conclusion - CC BY-SA 4.0
- 6: The Microphone - CC BY-SA 4.0
 - 6.1: Introduction - CC BY-SA 4.0
 - 6.2: Transducer - CC BY-SA 4.0
 - 6.3: Impedance - CC BY-SA 4.0
 - 6.4: Dynamic vs. Condenser vs. Ribbon - CC BY-SA 4.0
 - 6.5: Moving Coil Principle - CC BY-SA 4.0
 - 6.6: Ribbon Mic Principle - CC BY-SA 4.0
 - 6.7: Condenser Mic Principle - CC BY-SA 4.0
 - 6.8: Microphone Construction - CC BY-SA 4.0
 - 6.9: Directional Response - CC BY-SA 4.0
 - 6.10: Frequency Response - CC BY-SA 4.0
 - 6.11: Mic Limitations - CC BY-SA 4.0
 - 6.12: Proximity Effect - CC BY-SA 4.0
 - 6.13: Humbucker Coils in Microphones - CC BY-SA 4.0
 - 6.14: Lavalier Mic Properties and Uses - CC BY-SA 4.0
 - 6.15: Other Varieties of Mics - CC BY-SA 4.0
 - 6.16: Wireless Mics - CC BY-SA 4.0
 - 6.17: Microphone Accessories - CC BY-SA 4.0
 - 6.18: XLR Cables - CC BY-SA 4.0
 - 6.19: Conclusion - CC BY-SA 4.0
- 7: Speakers and Headphones - CC BY-SA 4.0
 - 7.1: Introduction - CC BY-SA 4.0
 - 7.2: The Audio Signal Chain - CC BY-SA 4.0
 - 7.3: Speaker Function - CC BY-SA 4.0
 - 7.4: The Speaker as a Transducer - CC BY-SA 4.0
 - 7.5: Types of Speakers - CC BY-SA 4.0
 - 7.6: Drivers and Frequency Bands - CC BY-SA 4.0
 - 7.7: Speaker Cabinet Design and Construction - CC BY-SA 4.0
 - 7.8: Active vs. Passive Speakers - CC BY-SA 4.0
 - 7.9: Polarity and Phase - CC BY-SA 4.0
 - 7.10: Crossover Networks - CC BY-SA 4.0
 - 7.11: Bi-Amplification - CC BY-SA 4.0
 - 7.12: Power Amplifiers - CC BY-SA 4.0
 - 7.13: Characteristics of Monitoring Systems - CC BY-SA 4.0
 - 7.14: Monitoring Systems- Stereo and Mono - CC BY-SA 4.0
 - 7.15: Headphones - CC BY-SA 4.0
 - 7.16: Headphone Monitoring in Studios - CC BY-SA 4.0
 - 7.17: Conclusion - CC BY-SA 4.0
- 8: Audio Signal Processing and Processors - CC BY-SA 4.0
 - 8.1: Introduction - CC BY-SA 4.0
 - 8.2: Function of a Signal Processor - CC BY-SA 4.0
 - 8.3: Spectrum Processors - CC BY-SA 4.0
 - 8.4: Time Domain Processors - CC BY-SA 4.0
 - 8.5: Amplitude Processors - CC BY-SA 4.0
 - 8.6: Noise Processors - CC BY-SA 4.0
 - 8.7: External vs. Internal Signal Processors - CC BY-SA 4.0
 - 8.8: Digital vs. Analog Signal Processing - CC BY-SA 4.0
 - 8.9: Conclusion - CC BY-SA 4.0
- 9: The Mixing Process - CC BY-SA 4.0
 - 9.1: Introduction - CC BY-SA 4.0
 - 9.2: Purpose of Mixing - CC BY-SA 4.0
 - 9.3: Layering vs. Balancing - CC BY-SA 4.0
 - 9.4: Mixing Perspective and Panning (Music Focused) - CC BY-SA 4.0
 - 9.5: Stages of the Mixing Process - CC BY-SA 4.0
 - 9.6: The Mastering Process - CC BY-SA 4.0
 - 9.7: Signal Processing in Mixing - CC BY-SA 4.0
 - 9.8: Dynamic Range - CC BY-SA 4.0

- 9.9: Audio Imaging for TV and Film - *CC BY-SA 4.0*
- 9.10: Surround Sound Mixing - *CC BY-SA 4.0*
- 9.11: Conclusion - *CC BY-SA 4.0*
- 10: Audio Over the Internet - *CC BY-SA 4.0*
 - 10.1: Introduction - *CC BY-SA 4.0*
 - 10.2: Streaming Audio - *CC BY-SA 4.0*
 - 10.3: Subscription-Based Listening - *CC BY-SA 4.0*
 - 10.4: Audio File Formats - *CC BY-SA 4.0*
 - 10.5: Audio File Size and Bitrate Considerations - *CC BY-SA 4.0*
 - 10.6: Audio Quality vs. File Size - *CC BY-SA 4.0*
 - 10.7: Podcasting - *CC BY-SA 4.0*
 - 10.8: What Happened to Terrestrial Radio? - *CC BY-SA 4.0*
 - 10.9: Alternatives to Streaming - *CC BY-SA 4.0*
 - 10.10: The Future of Audio - *CC BY-SA 4.0*
 - 10.11: Conclusion - *CC BY-SA 4.0*
- Back Matter - *CC BY-SA 4.0*
 - Index - *CC BY-SA 4.0*
 - Glossary - *CC BY-SA 4.0*
 - Detailed Licensing - *CC BY-SA 4.0*
 - Video Tutorials - *CC BY-SA 4.0*
 - Detailed Licensing - *Undeclared*

Video Tutorials

YouTube Video Tutorials

This [YouTube channel](#)([opens in new window](#)) is dedicated to teaching digital audio fundamentals and practical audio production skills using Pro Tools on both Mac and PC platforms. The channel focuses on clear, step-by-step instructional videos that help beginners and aspiring audio engineers learn how to record, edit, and produce professional-quality projects. Topics include voiceover recording and editing, creating radio station IDs and promos, organizing and editing pre-existing audio assets, and building efficient Pro Tools workflows. Whether you're new to digital audio or looking to strengthen your production skills, these tutorials provide practical techniques and real-world projects designed to help you confidently create and manage audio in a professional environment.

MAC Video Tutorials By Project

1. [Lab 1 Pro Tools Download and Install](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
2. [Lab 2 Pro Tools Importing Audio](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
3. [Lab 3 Pro Tools Station ID and Music Bed](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
4. [Lab 4 Pro Tools Edit #1 Project](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
5. [Lab 5 Pro Tools Edit #2 Project](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
6. [Lab 6 Pro Tools Edit #3 Project](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
7. [Lab 7 GarageBand Music Bed](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
8. [Lab 8 Pro Tools PSA with Music Bed](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
9. [Lab 9 Pro Tools Mixing a Song](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
10. [Lab 10 Pro Tools Final 4 Minute Show](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))

PC Video Tutorials By Project

1. [Lab 1 Pro Tools Download and Install](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
2. [Lab 2 Pro Tools Importing Audio](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
3. [Lab 3 Pro Tools Station ID and Music Bed](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
4. [Lab 4 Pro Tools Edit #1 Project](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
5. [Lab 5 Pro Tools Edit #2 Project](#) ([opens in new window](#))
 1. [Video Transcript File](#) ([opens in new window](#))
6. [Lab 6 Pro Tools Edit #3 Project](#) ([opens in new window](#))

1. [Video Transcript File \(opens in new window\)](#)
7. [Lab 7 Music Maker Music Bed \(opens in new window\)](#)
 1. [Video Transcript File \(opens in new window\)](#)
8. [Lab 8 Pro Tools PSA with Music Bed \(opens in new window\)](#)
 1. [Video Transcript File \(opens in new window\)](#)
9. [Lab 9 Pro Tools Mixing a Song \(opens in new window\)](#)
 1. [Video Transcript File \(opens in new window\)](#)
10. [Lab 10 Pro Tools Final 4 Minute Show \(opens in new window\)](#)
 1. [Video Transcript File \(opens in new window\)](#)

Detailed Licensing

Overview

Title: [Understanding Sound From Ear to Engineer](#)

Webpages: 150

All licenses found:

- [CC BY-SA 4.0](#): 98.7% (148 pages)
- [Undeclared](#): 1.3% (2 pages)

By Page

- [Understanding Sound From Ear to Engineer](#) - [CC BY-SA 4.0](#)
 - [Front Matter](#) - [CC BY-SA 4.0](#)
 - [TitlePage](#) - [CC BY-SA 4.0](#)
 - [InfoPage](#) - [CC BY-SA 4.0](#)
 - [Table of Contents](#) - [Undeclared](#)
 - [Licensing](#) - [CC BY-SA 4.0](#)
 - [1: The Characteristics of Sound](#) - [CC BY-SA 4.0](#)
 - [1.1: Introduction](#) - [CC BY-SA 4.0](#)
 - [1.2: The Sound Wave](#) - [CC BY-SA 4.0](#)
 - [1.3: Frequency](#) - [CC BY-SA 4.0](#)
 - [1.4: Amplitude](#) - [CC BY-SA 4.0](#)
 - [1.5: Velocity](#) - [CC BY-SA 4.0](#)
 - [1.6: Wavelength](#) - [CC BY-SA 4.0](#)
 - [1.7: Acoustical Phase](#) - [CC BY-SA 4.0](#)
 - [1.8: Sound Envelope](#) - [CC BY-SA 4.0](#)
 - [1.9: Direct, Early, and Reverberant Sound](#) - [CC BY-SA 4.0](#)
 - [1.10: Conclusion](#) - [CC BY-SA 4.0](#)
 - [2: The Auditory System](#) - [CC BY-SA 4.0](#)
 - [2.1: Introduction](#) - [CC BY-SA 4.0](#)
 - [2.2: The Ear](#) - [CC BY-SA 4.0](#)
 - [2.3: How Hearing Works](#) - [CC BY-SA 4.0](#)
 - [2.4: Hearing Loss](#) - [CC BY-SA 4.0](#)
 - [2.5: Symptoms of Hearing Loss](#) - [CC BY-SA 4.0](#)
 - [2.6: Hearing Protection](#) - [CC BY-SA 4.0](#)
 - [2.7: Hearing Aids and Cochlear Implants](#) - [CC BY-SA 4.0](#)
 - [2.8: Fun Fact. How Loud Is Too Loud?](#) - [CC BY-SA 4.0](#)
 - [2.9: Sound Pressure Level \(SPL\)](#) - [CC BY-SA 4.0](#)
 - [2.10: Tinnitus- The Ringing in the Ears](#) - [CC BY-SA 4.0](#)
 - [2.11: Conclusion](#) - [CC BY-SA 4.0](#)
 - [3: Psychoacoustics](#) - [CC BY-SA 4.0](#)
 - [3.1: Introduction](#) - [CC BY-SA 4.0](#)
 - [3.2: Properties of Sound](#) - [CC BY-SA 4.0](#)
 - [3.3: Frequency Spectrum](#) - [CC BY-SA 4.0](#)
 - [3.4: Octave Groupings](#) - [CC BY-SA 4.0](#)
 - [3.5: Instrument Ranges](#) - [CC BY-SA 4.0](#)
 - [3.6: Equal Loudness Principle](#) - [CC BY-SA 4.0](#)
 - [3.7: Quality of Sound \(Timbre\)](#) - [CC BY-SA 4.0](#)
 - [3.8: Binaural Hearing vs. Stereo Hearing](#) - [CC BY-SA 4.0](#)
 - [3.9: Conclusion](#) - [CC BY-SA 4.0](#)
 - [4: Audio Mixers, Consoles, and DAW Control Surfaces](#) - [CC BY-SA 4.0](#)
 - [4.1: Introduction](#) - [CC BY-SA 4.0](#)
 - [4.2: Faders vs. Knobs](#) - [CC BY-SA 4.0](#)
 - [4.3: Passive vs. Active](#) - [CC BY-SA 4.0](#)
 - [4.4: Function of a Mixer/Console](#) - [CC BY-SA 4.0](#)
 - [4.5: Balance and Combine Levels](#) - [CC BY-SA 4.0](#)
 - [4.6: Monitoring and Metering](#) - [CC BY-SA 4.0](#)
 - [4.7: The Mix Bus and Bussing](#) - [CC BY-SA 4.0](#)
 - [4.8: Routing and Signal Flow](#) - [CC BY-SA 4.0](#)
 - [4.9: Major Sections of a Mixer/Console](#) - [CC BY-SA 4.0](#)
 - [4.10: Broadcast vs. Production Consoles](#) - [CC BY-SA 4.0](#)
 - [4.11: Features of Most Consoles](#) - [CC BY-SA 4.0](#)
 - [4.12: The Audio Patchbay](#) - [CC BY-SA 4.0](#)
 - [4.13: Automation](#) - [CC BY-SA 4.0](#)
 - [4.14: DAW Control Surfaces](#) - [CC BY-SA 4.0](#)
 - [4.15: Conclusion](#) - [CC BY-SA 4.0](#)
 - [5: Audio Recording](#) - [CC BY-SA 4.0](#)
 - [5.1: Introduction](#) - [CC BY-SA 4.0](#)
 - [5.2: Digital vs. Analog](#) - [CC BY-SA 4.0](#)
 - [5.3: Sample Rate](#) - [CC BY-SA 4.0](#)
 - [5.4: Nyquist-Shannon Theory](#) - [CC BY-SA 4.0](#)
 - [5.5: Bit Depth \(Resolution\)](#) - [CC BY-SA 4.0](#)
 - [5.6: Quantization](#) - [CC BY-SA 4.0](#)
 - [5.7: Binary Code](#) - [CC BY-SA 4.0](#)
 - [5.8: Common Recording Systems](#) - [CC BY-SA 4.0](#)
 - [5.9: The Digital Audio Workstation](#) - [CC BY-SA 4.0](#)

- 5.10: Audio Interface - CC BY-SA 4.0
- 5.11: Digital Audio Connections - CC BY-SA 4.0
- 5.12: Recording Media Types - CC BY-SA 4.0
- 5.13: MIDI and Its Use - CC BY-SA 4.0
- 5.14: Analog Audio Connectors - CC BY-SA 4.0
- 5.15: Digital Audio Networking - CC BY-SA 4.0
- 5.16: Conclusion - CC BY-SA 4.0
- 6: The Microphone - CC BY-SA 4.0
 - 6.1: Introduction - CC BY-SA 4.0
 - 6.2: Transducer - CC BY-SA 4.0
 - 6.3: Impedance - CC BY-SA 4.0
 - 6.4: Dynamic vs. Condenser vs. Ribbon - CC BY-SA 4.0
 - 6.5: Moving Coil Principle - CC BY-SA 4.0
 - 6.6: Ribbon Mic Principle - CC BY-SA 4.0
 - 6.7: Condenser Mic Principle - CC BY-SA 4.0
 - 6.8: Microphone Construction - CC BY-SA 4.0
 - 6.9: Directional Response - CC BY-SA 4.0
 - 6.10: Frequency Response - CC BY-SA 4.0
 - 6.11: Mic Limitations - CC BY-SA 4.0
 - 6.12: Proximity Effect - CC BY-SA 4.0
 - 6.13: Humbucker Coils in Microphones - CC BY-SA 4.0
 - 6.14: Lavalier Mic Properties and Uses - CC BY-SA 4.0
 - 6.15: Other Varieties of Mics - CC BY-SA 4.0
 - 6.16: Wireless Mics - CC BY-SA 4.0
 - 6.17: Microphone Accessories - CC BY-SA 4.0
 - 6.18: XLR Cables - CC BY-SA 4.0
 - 6.19: Conclusion - CC BY-SA 4.0
- 7: Speakers and Headphones - CC BY-SA 4.0
 - 7.1: Introduction - CC BY-SA 4.0
 - 7.2: The Audio Signal Chain - CC BY-SA 4.0
 - 7.3: Speaker Function - CC BY-SA 4.0
 - 7.4: The Speaker as a Transducer - CC BY-SA 4.0
 - 7.5: Types of Speakers - CC BY-SA 4.0
 - 7.6: Drivers and Frequency Bands - CC BY-SA 4.0
 - 7.7: Speaker Cabinet Design and Construction - CC BY-SA 4.0
 - 7.8: Active vs. Passive Speakers - CC BY-SA 4.0
 - 7.9: Polarity and Phase - CC BY-SA 4.0
 - 7.10: Crossover Networks - CC BY-SA 4.0
 - 7.11: Bi-Amplification - CC BY-SA 4.0
 - 7.12: Power Amplifiers - CC BY-SA 4.0
 - 7.13: Characteristics of Monitoring Systems - CC BY-SA 4.0
 - 7.14: Monitoring Systems- Stereo and Mono - CC BY-SA 4.0
 - 7.15: Headphones - CC BY-SA 4.0
 - 7.16: Headphone Monitoring in Studios - CC BY-SA 4.0
 - 7.17: Conclusion - CC BY-SA 4.0
- 8: Audio Signal Processing and Processors - CC BY-SA 4.0
 - 8.1: Introduction - CC BY-SA 4.0
 - 8.2: Function of a Signal Processor - CC BY-SA 4.0
 - 8.3: Spectrum Processors - CC BY-SA 4.0
 - 8.4: Time Domain Processors - CC BY-SA 4.0
 - 8.5: Amplitude Processors - CC BY-SA 4.0
 - 8.6: Noise Processors - CC BY-SA 4.0
 - 8.7: External vs. Internal Signal Processors - CC BY-SA 4.0
 - 8.8: Digital vs. Analog Signal Processing - CC BY-SA 4.0
 - 8.9: Conclusion - CC BY-SA 4.0
- 9: The Mixing Process - CC BY-SA 4.0
 - 9.1: Introduction - CC BY-SA 4.0
 - 9.2: Purpose of Mixing - CC BY-SA 4.0
 - 9.3: Layering vs. Balancing - CC BY-SA 4.0
 - 9.4: Mixing Perspective and Panning (Music Focused) - CC BY-SA 4.0
 - 9.5: Stages of the Mixing Process - CC BY-SA 4.0
 - 9.6: The Mastering Process - CC BY-SA 4.0
 - 9.7: Signal Processing in Mixing - CC BY-SA 4.0
 - 9.8: Dynamic Range - CC BY-SA 4.0
 - 9.9: Audio Imaging for TV and Film - CC BY-SA 4.0
 - 9.10: Surround Sound Mixing - CC BY-SA 4.0
 - 9.11: Conclusion - CC BY-SA 4.0
- 10: Audio Over the Internet - CC BY-SA 4.0
 - 10.1: Introduction - CC BY-SA 4.0
 - 10.2: Streaming Audio - CC BY-SA 4.0
 - 10.3: Subscription-Based Listening - CC BY-SA 4.0
 - 10.4: Audio File Formats - CC BY-SA 4.0
 - 10.5: Audio File Size and Bitrate Considerations - CC BY-SA 4.0
 - 10.6: Audio Quality vs. File Size - CC BY-SA 4.0
 - 10.7: Podcasting - CC BY-SA 4.0
 - 10.8: What Happened to Terrestrial Radio? - CC BY-SA 4.0
 - 10.9: Alternatives to Streaming - CC BY-SA 4.0
 - 10.10: The Future of Audio - CC BY-SA 4.0
 - 10.11: Conclusion - CC BY-SA 4.0
- Back Matter - CC BY-SA 4.0
 - Index - CC BY-SA 4.0
 - Glossary - CC BY-SA 4.0
 - Detailed Licensing - CC BY-SA 4.0
 - Video Tutorials - CC BY-SA 4.0

- [Detailed Licensing](#) - *Undeclared*